

## Contents

### Basic Operations

General Guide

Using the Crown

Hands and the Day Indicator

Solar Charging

### Using Mobile Link with a Mobile Phone

Getting Ready

- ① Installing required app on your phone
- ② Configuring Bluetooth settings
- ③ Pairing the watch with a phone

Auto Time Adjustment

Configuring World Time Settings

Correcting Hand Alignment

Phone Finder

Configuring Watch Settings

Changing the Home City Summer Time Setting

Checking the Watch Charge Level

Connection

- Connecting with a Phone
- Disconnecting from a Phone
- Using the Watch in a Medical Facility or Aircraft
- Unpairing
- If you purchase another phone

### Watch Settings

Setting the Time and Date

Configuring Dual Time Settings

Swapping Your Current Location Time and Dual Time

### Hand Alignment Correction

To correct hand alignment

### Moving To Another Time Zone

### Other Information

Summer Time Switching

Supported Phone Models

Specifications

Mobile Link Precautions

Copyrights and Registered Copyrights

### Troubleshooting


## Basic Operations

This section provides an overview of the watch and its operations.

### Note

- The illustrations included in this operation guide have been created to facilitate explanation. An illustration may differ somewhat from the item it represents.


## General Guide



- Battery indicator**  
Shows the watch's charge status as one of seven levels. The indicator hand points to the watch's current charge level.
- Hour and minute hands**  
Indicate the current time in your current location (Home City).
- R mark**  
When the watch is standing by for connection with a phone, the day of the week hand points to "R".
- Day of the week hand**  
Indicates the day of the week in your current location (Home City).
- Small hour and minute hands**  
Indicate the current time in your World Time (Dual Time) City.
- Second hand**  
Indicates the current second in your current location (Home City).
- Small 24-hour hand**  
Indicates the current 24-hour time in your World Time (Dual Time) City. Points to the A-side for a.m. times, and to the P-side for p.m. times.
- P-A mark**  
Used when configuring current time settings in your current location (Home City). "A" indicates an a.m. time setting, while "P" indicates a p.m. time setting.
- Day**  
Indicates the current day in your current location (Home City).
- ✂ mark**  
When the watch is connected with a phone, the day of the week hand points to ✂.

## Using the Crown


The watch's crown is a screw-in (screw lock) type. To use the crown, you first need to rotate it towards you (leftwards) to loosen it.



### ● Pulling Out and Pushing In the Crown

Before performing a crown operation, you need to pull it out to the first or second click as shown in the figures below. Do not pull the crown with too much force.

#### First click




#### Second click



### Important!

- To prevent loss of water resistance and/or damage due to impact, be sure to screw the crown in by rotating it away from you as you push it in.



- When pushing the crown back in, take care not to apply too much force.

### ● Fast Forward/Fast Reverse

After pulling out the crown, rotating it quickly in succession in either direction will cause the hands to move forward or back at high speed. While the hands are moving forward at high speed, quickly rotating the crown in succession again will increase the speed even further.


### ● Stopping Fast Forward/Fast Reverse

Rotate the crown in the direction opposite that of the ongoing operation or press any button.

### Note

- If you do not perform any operation for about nine minutes after pulling out the crown, crown operations will automatically become disabled. If that happens, push the crown back in and then pull it out again.

## Hands and the Day Indicator



### ● Battery Indicator and Day Indicator Movement

Changing the day setting of the watch will also cause the battery indicator hand to move in conjunction with the day indicator.

### ● Hour and Minute Hand Operation

The minute hand of this watch moves in conjunction with second hand movement.

### ● Day

- It can take anywhere from about 90 seconds to three minutes for the day indicator to change after timekeeping reaches midnight. The battery indicator hand will move as the day indicator changes.
- The day may not be indicated correctly while the watch's crown is pulled out.

## Solar Charging


This watch runs on power supplied from a rechargeable (secondary) battery that is charged by a solar panel. The solar panel is integrated into the face of the watch, and power is generated whenever the face is exposed to light.

### ● Charging the Watch

When you are not wearing the watch, put it in a location where it is exposed to bright light.



While you are wearing the watch, make sure that its face (solar panel) is not blocked from light by the sleeve of your clothing. Power generation efficiency is reduced even when the face of the watch is blocked only partially.



### Important!

- Depending on light intensity and local conditions, the watch may become hot to the touch when exposed to light for charging. Take care to avoid burn injury after charging. Also, avoid charging the watch under high-temperature conditions like the ones described below.
  - On the dashboard of a vehicle parked in the sun
  - Near an incandescent light bulb or other source of heat
  - Under direct sunlight or in other hot areas for long periods

### ● Checking the Charge Level

You can determine the watch's current charge level by checking the position of the battery indicator hand.



- ① Fully charged
- ② Charged
- ③ Low
- ④ Dead

### ● Remaining Charge and Dead Battery

You can determine if the charge level is low by checking the hand movement. Functions become disabled as battery power goes low.

### Important!

- Should the battery go low or go dead, expose the face (solar panel) to light as soon as possible.

### Note

- Exposing the watch face to light after the battery goes dead will cause the second hand to revolve counterclockwise until it stops at second 57. This indicates charging has started.

### Low Battery Power

The second hand jumps at two-second intervals.



Second hand

### Dead Battery

All hands and the day indicator are stopped.



### ● Charging Time Guidelines

The table below shows guidelines for approximate charging times.

#### Charging Times Required for 1 Day of Operation

Light Intensity		Approximate Charging Time
High	①	8 minutes
	②	30 minutes
Low	③	48 minutes
	④	8 hours

#### Charge Recovery Times

Light Intensity	Approximate Charging Time	
	Charge Level 1	Charge Level 2
High	①	2 hours
	②	5 hours
Low	③	8 hours
	④	82 hours

#### Light Intensity

- ① Sunny day, outdoors (50,000 lux)
- ② Sunny day, near a window (10,000 lux)
- ③ Overcast day, near a window (5,000 lux)
- ④ Indoor fluorescent lighting (500 lux)

#### Charge Level 1 :

Time from dead battery until watch operation starts.

#### Charge Level 2 :

Time from watch operation start until a full charge.

### ● Power Saving

Leaving the watch in a dark location for approximately one week will cause movement all of the watch's hands to stop in order to save power.

- Only the day indicator is operational.

#### Recovering from Power Saving Operation

Press any button or place the watch in a well-lit area to recover from power saving.

## Using Mobile Link with a Mobile Phone

While there is a Bluetooth connection between the watch and phone, the watch time setting is adjusted automatically in accordance with the phone's time setting.

### Note

- This function is available only while CASIO WATCHES is running on the phone.
- This section describes watch and phone operations.
- 🕒 : Watch operation
- 📱 : Phone operation

## Getting Ready

### ① Installing required app on your phone

In Google Play or the App Store, search for the "CASIO WATCHES" phone app and install it on your phone.

### ② Configuring Bluetooth settings

Enable the phone's Bluetooth.


### Note

- For details about setting procedures, see your phone documentation.

### ③ Pairing the watch with a phone

Before you can use the watch in combination with a phone, you first need to pair them.

1. Move the phone to be paired with close to (within one meter of) the watch.
2. 📱 Tap the "CASIO WATCHES" icon.
3. 🕒 Tap the + of the "My Watch" tab.
4. 📱 Perform the operation shown on the phone screen to register the watch to the CASIO WATCHES phone app.
5. 🕒 Hold down (B) for at least 1.5 seconds. Release the button when the day of the week hand moves to "R".
  - The day of the week hand will move to 🕒 when a connection is established between the watch and phone.
  - If pairing fails, the watch returns to the state it was in before starting this procedure. Perform the pairing procedure again from the beginning.



### Note

- The first time you start up the CASIO WATCHES phone app, a message will appear on your phone asking if you want to enable location information acquisition. Configure settings to allow background use of location information.

## Auto Time Adjustment

You can configure watch settings to connect with a phone at preset times each day and adjust its time settings in accordance with information obtained from an online time server.

### ● Using This Function

Your watch adjusts its time setting four times a day. It performs the adjustment operation automatically as you go about your daily life, without any operation required by you.



### Important!

- The watch may not be able to perform auto time setting adjustment under the conditions described below.
  - While the watch is too far away from its paired phone
  - While communication is not possible due to radio interference, etc.
  - While the phone is updating its system

### Note

- If there is a World Time City specified with CASIO WATCHES, its time will also be adjusted automatically.
- The watch will connect with the phone and perform auto time adjustment at around 5:00 a.m., 11:00 a.m., 5:00 p.m. and 11:00 p.m. The connection is automatically terminated after auto time adjustment is complete.

## ● Summer Time

Once the watch is connected with a phone and its time is corrected with the phone time, its Home City time and World Time will automatically switch between standard time and summer time as required, even if the watch is no longer connected with the phone.

### 🔗 Summer Time Switching

- Changing the time setting manually with a watch operation will cancel auto standard time/summer time switching.
- A CASIO WATCHES screen shows information about summer time periods.

## ● Triggering Immediate Time Correction

The watch will adjust its time setting to that of the phone immediately after they are connected with each other. Whenever you want to adjust the watch's time setting perform the procedure below to connect with a phone.

1. 📱 On the Home Screen, tap the "CASIO WATCHES" icon.

2. 🕒 Press (B).


This causes the day of the week hand to move to "R". The day of the week hand will move to 🕒 when a connection is established between the watch and phone, and the time setting of the watch will adjust to the phone's time setting.

- The connection is terminated automatically after time adjustment is complete.



## Configuring World Time Settings

Specifying a World Time City with CASIO WATCHES causes the city's time to be indicated by the small hour and minute hands. Watch settings can be configured for auto summer time switching for the World Time City.



### Note


- CASIO WATCHES World Time lets you select from among approximately 300 cities as the World Time City.

## ● To select a World Time City

1. 📱 Tap the "CASIO WATCHES" icon.


2. 🕒 Hold down the (B) button for about 1.5 seconds.

- The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
- The day of the week hand will move to 🕒 when a connection is established between the watch and phone.



3. 📱 Perform the operation shown on the phone screen. The World Time setting will be reflected on the watch.

- You can determine whether a World Time is a.m. or p.m. by checking the position of the small 24-hour hand.




## ● Configuring the Summer Time Setting

1. 📱 Tap the "CASIO WATCHES" icon.

2. 🕒 Hold down the (B) button for about 1.5 seconds.

- The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
- The day of the week hand will move to 🕒 when a connection is established between the watch and phone.




- Perform the operation shown on the phone screen to configure the summer time setting.
  - “Auto”**  
The watch switches between standard time and summer time automatically.
  - “OFF”**  
The watch always indicates standard time.
  - “ON”**  
The watch always indicates summer time.

## Note

- When “Auto” is selected for standard/summer time switching, the watch will switch between standard time and summer time automatically. You do not need to change the time setting manually for changes between summer time and standard time. Even if you are in an area that does not observe summer time, you can leave the watch’s summertime setting as “Auto”.
- Changing the time setting manually with a watch operation will cancel auto standard time/summer time switching.
- A CASIO WATCHES screen shows information about summer time periods.


## ● Swapping Your World Time and Home Time

- Tap the “CASIO WATCHES” icon.
- Hold down the (B) button for about 1.5 seconds.
  - The day of the week hand will move to “R”. Keep (B) depressed until the day of the week hand starts moving again and then stops at “R”.
  - The day of the week hand will move to when a connection is established between the watch and phone.



- Perform the operation shown on the phone screen to swap your Home Time with your World Time.

For example, if your Home City is Tokyo and the World Time City is New York, they will be swapped as shown below.




## Note

- Auto time adjustment is not performed for 24 hours after swapping of the Home Time and World Time.

## Correcting Hand Alignment

If the hands are out of alignment even though auto time adjustment is being performed, use CASIO WATCHES to adjust them.

- Tap the “CASIO WATCHES” icon.
- Hold down the (B) button for about 1.5 seconds.
  - The day of the week hand will move to “R”. Keep (B) depressed until the day of the week hand starts moving again and then stops at “R”.
  - The day of the week hand will move to when a connection is established between the watch and phone.



- Perform the operation shown on the phone screen to correct hand alignment.


## Phone Finder

You can use phone finder to trigger a tone on the phone to make it easy to find. The tone is forced to sound even if the phone is in vibrate mode.


### Important!

- Do not use this function in areas where phone call tones are restricted.
- The tone sounds at a high volume. Do not use this function when listening to phone output over earphones.


- If the watch is connected with a phone, press (B) to terminate the connection.



- Hold down the (C) button for about 0.5 seconds until the day of the week hand points to "R".

The day of the week hand will move to  when a connection is established between the watch and phone, and then the phone's ringtone will sound.


- It takes a few seconds before the phone tone sounds.




- Press any button to stop the tone.
  - You can press any watch button to stop the phone tone, but only during the first 30 seconds after it starts to sound.

## Configuring Watch Settings


You can use CASIO WATCHES to specify the amount of time until the Bluetooth connection is automatically terminated, and to configure other settings.


- Tap the "CASIO WATCHES" icon.
- Hold down the (B) button for about 1.5 seconds.
  - The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
  - The day of the week hand will move to  when a connection is established between the watch and phone.



- Select the setting you want to change and then perform the operation shown on the phone screen.

## Changing the Home City Summer Time Setting


- On the Home Screen, tap the "CASIO WATCHES" icon.
- Hold down the (B) button for about 1.5 seconds.
  - The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
  - The day of the week hand will move to  when a connection is established between the watch and phone.




- Perform the operation shown on the phone screen to change your Home City summer time setting.

## Checking the Watch Charge Level

Use the procedure below to check the current charge level with CASIO WATCHES.

- On the Home Screen, tap the "CASIO WATCHES" icon.
- Hold down the (B) button for about 1.5 seconds.
  - The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
  - The day of the week hand will move to  when a connection is established between the watch and phone.






- Use CASIO WATCHES to check the charge level.

## Connection

### Connecting with a Phone

This section explains how to establish a Bluetooth connection with a phone that is paired with the watch.

- If the watch is not paired with the phone you want to connect with, perform the procedure under "[③ Pairing the watch with a phone](#)" to pair them.
- Move the phone close to (within one meter of) the watch.
  - If the day of the week hand is not pointing to , hold down the (B) button for about 1.5 seconds.
    - The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
    - The day of the week hand will move to  when a connection is established between the watch and phone.



## Important!


- If you have problems establishing a connection, it could mean that CASIO WATCHES is not running on the phone. On the phone's home screen, tap the "CASIO WATCHES" icon. After the app starts up, hold down the watch's (B) button for about 1.5 seconds.

## Note

- The connection is terminated if you do not perform any operation on the watch or phone for a fixed amount of time. To specify the connection limit time, perform the following operation with the CASIO WATCHES phone app: "Watch settings" → "Connection time with the app". Next, select a setting of 3 minutes, 5 minutes, or 10 minutes.

## Disconnecting from a Phone


Pressing (B) terminates the Bluetooth connection and returns the day of the week hand to its normal operation.



## Using the Watch in a Medical Facility or Aircraft

Whenever you are in a hospital, on an aircraft, or in any other location where auto time adjustment may cause problems, you can perform the procedure below to disable it. Perform the same procedure again to re-enable auto time adjustment.


1. On the Home Screen, tap the "CASIO WATCHES" icon.
2. Hold down the (B) button for about 1.5 seconds.
  - The day of the week hand will move to "R". Keep (B) depressed until the day of the week hand starts moving again and then stops at "R".
  - The day of the week hand will move to when a connection is established between the watch and phone.



3. Perform the operation shown on the phone screen to enable or disable auto time adjustment.

## Unpairing

1. If the watch is connected with a phone, press (B) to terminate the connection.




2. Tap the "CASIO WATCHES" icon.
3. Perform the operation shown on the phone screen to unpair.

## Note

- If you are unable to re-pair the watch with a phone after unpairing them, use the procedure below to delete pairing information from the watch and then perform the pairing operation again.

1. Pull out the crown to the second click.



2. Hold down (C) for about five seconds.

This causes the day of the week hand to perform one revolution and deletes the pairing information.

3. Push the crown back in.

## If you purchase another phone

You need to perform the operation below whenever you want to establish a Bluetooth connection with a phone that is different from the one you are currently connected with.

[Pairing the Watch with a phone](#)


## Watch Settings

Use the procedure below to configure current location time and Dual Time settings manually.


### Setting the Time and Date

While the watch is connected to a phone, it will automatically correct its day and time settings to those of the phone. If the watch is not connected to a phone, use the procedure below to adjust its day and time settings.


1. Pull out the crown to the second click.  
This causes the second hand to move to 12 o'clock, and enables the minute setting operation.




2. Rotate the crown to change the minute setting.
  - The Dual Time setting is also adjusted in accordance with the current time setting.
3. Press (B).  
This enables the hour setting operation.
4. Rotate the crown to change the hour setting.
  - Use the day of the week hand to check if the time is a.m. or p.m.




5. Press (B).  
This enables the year 10's digit setting operation.
6. Rotate the crown to change the year 10's digit.




7. Press (B).  
This enables the year one's digit setting operation.
8. Rotate the crown to change the year one's digit.



9. Press (B).  
This enables the month setting operation.
10. Rotate the crown to change the month setting.




11. Press (B).  
This enables the day setting operation.
12. Rotate the crown to change the day.




13. On a time signal at the top of a minute, push the crown back in.

## Configuring Dual Time Settings

Dual Time lets you keep track of the current time in another time zone in addition your current location time.




1. Pull out the crown to the first click.
2. Rotate the crown to change the Dual Time setting.
  - You can set the Dual Time in 15-minute increments.
  - You can find out whether the Dual Time is showing an a.m. or p.m. time by checking the small 24-hour hand.



3. Push the crown back in.

## Swapping Your Current Location Time and Dual Time

You can swap your Home Time with the Dual Time by holding down (A) for about three seconds.



### Note


- If the current times were set manually on the watch (not automatically by the phone), the dates will not be swapped. Only the times are swapped.

## Hand Alignment Correction


Strong magnetism or impact can cause the time indicated by the hands and the day indicator to go out of alignment. If this happens, correct hand alignment.

### To correct hand alignment


1. Pull out the crown to the first click.
2. Hold down (C) for about five seconds.  
This enables adjustment of second and minute hand alignment.



3. Rotate the crown to align the second and minute hands with 12 o'clock.
4. Press (B).  
This enables adjustment of hour hand alignment.




5. Rotate the crown to align the hour hand with 12 o'clock.
6. Press (B).  
This enables adjustment of small hour and minute hand, and small 24-hour hand alignment.




7. Rotate the crown to align the small hour and minute hands, and the small 24-hour hand with 12 o'clock.


8. Press (B).  
This enables adjustment of day of the week setting.



9. Rotate the crown to align the day of the week hand with "R".
10. Press (B).  
This enables adjustment of battery indicator hand alignment.



11. Rotate the crown to align the battery indicator hand with "F".
12. Press (B).  
This enables adjustment of day indicator alignment.




13. Rotate the crown to align "1" in the center of the day indicator.
  - The battery indicator hand will move along with the day indicator setting. Also make sure that the battery indicator hand aligns with "F".
14. Push the crown back in.

## Moving To Another Time Zone

Use the procedure below to easily change day and time settings of the watch to a destination location.

### ● Before Boarding

1. Configure the World Time (Dual Time) to the current time at your destination.




- 🔗 [Configuring World Time Settings](#)
- 🔗 [Configuring Dual Time Settings](#)

2. Disable auto time adjustment.

- 🔗 [Using the Watch in a Medical Facility or Aircraft](#)

### ● After Arriving

1. Swap the origin time zone time with the destination time zone time.



- 🔗 [Swapping Your Current Location Time and Dual Time](#)

2. Enable auto time adjustment.

- 🔗 [Using the Watch in a Medical Facility or Aircraft](#)

## Other Information

This section provides non-operational information you also need to know. Refer to this information as required.

### Summer Time Switching

#### ● Connecting with a Phone to Switch

After the watch is connected with a phone, summer time switching of Home City time and World Time is performed in accordance with the CASIO WATCHES setting (Auto/ON/OFF) as described below.

#### Auto :

After the watch is connected with a phone, summer time is displayed for the current location time or World Time when it is within the summer time period. Otherwise standard time is displayed.

#### ON :

The watch always displays summer time.

#### OFF :

The watch always displays standard time.

#### ● Auto Summer Time Switching

When the watch is connected to a phone, it is sent summer time period information for your Home City. If there is a World Time City specified with CASIO WATCHES, information for that city will also be sent. If the CASIO WATCHES summer time setting is "Auto", the watch will automatically keep track of the summer time period and perform summer time switching automatically, even if it is not connected with the phone.

### Supported Phone Models

For information about supported phone models, visit the CASIO Website.

[https://world.casio.com/os\\_mobile/wat/](https://world.casio.com/os_mobile/wat/)

## Specifications

#### Accuracy at normal temperature :

±15 seconds per month

#### Timekeeping :

Hour, minute, second, day (2000 to 2099 full auto calendar), day of the week

#### Dual Time :

Hour and minute, 24-time indication, swapping with current location time

#### Mobile Link :

##### Auto Time Correction

Time setting corrected automatically at preset time

##### Phone finder

Watch operation sounds the alert sound of the phone.

##### Auto Summer Time Switching

Automatic switching between standard time and summer time

##### Hand position correction

##### Data Communication Specifications

##### Bluetooth®

Frequency Band: 2400MHz to 2480MHz

Maximum Transmission: 0 dBm (1 mW)

Communication range: Up to 2 meters

(depends on environment)

#### Other :

Power saving, low battery alert, battery level indication (battery indicator)

#### Power Supply :

Solar panel and one rechargeable battery (Type: CTL920)

Battery nominal voltage: 2.3V

#### Approximate Battery Life :

5 months

##### Conditions

Auto Time Adjustment: 4 times/day

## Mobile Link Precautions

### ● Legal Precautions

- This watch complies with or has received approval under the radio laws of various countries and geographical areas. Using this watch in an area where it does not comply with or has not received approval under applicable radio laws may be a criminal offense. For details, visit the CASIO Website.

<https://world.casio.com/ce/BLE/>

- Use of this watch inside of aircraft is restricted under the aviation laws of each country. Be sure to follow the instructions of airline personnel.

### ● Precautions when using Mobile Link

- When using this watch in combination with a phone, keep the watch and phone close to each other. A range of two meters is recommended as a guideline, but the local environment (walls, furniture, etc.), the structure of a building, and other factors may require a much closer range.
- This watch can be affected by other devices (electrical devices, audio-visual equipment, office equipment, etc.) In particular, it can be affected by operation of a microwave oven. The watch may not be able to communicate normally with a phone if a microwave oven is operating nearby. Conversely, this watch may cause noise in radio reception and the video image of a TV.
- Bluetooth of this watch uses the same frequency band (2.4 GHz) as wireless LAN devices, and use of such devices in close proximity of this watch may result in radio interference, slower communication speeds and noise for the watch and the wireless LAN device, or even communication failure.

### ● Stopping Radio Wave Emission by This Watch

The watch is emitting radio waves whenever the day of the week hand is pointing to (Bluetooth connected) or "R" (Bluetooth connection standby). Even if the day of the week hand is not pointing at or "R", the watch will attempt to connect with a phone four times a day to adjust its time settings.

When in a hospital, on an aircraft, or in any other area where the use of radio waves is not allowed, use CASIO WATCHES to disable syncing between the watch and phone.

For details, see "[Using the Watch in a Medical Facility or Aircraft](#)".

## Copyrights and Registered Copyrights

- Bluetooth® is a registered trademark of Bluetooth SIG, Inc.
- iPhone and App Store are trademarks of Apple Inc. in the United States and other countries.
- IOS is a trademark or registered trademark of Cisco Systems, Inc.
- Android and Google Play™ are trademarks or registered trademarks of Google LLC.
- Other company names and product names used herein are trademarks or registered trademarks of their respective companies.

## Troubleshooting

### I can't pair the watch with a phone.

**Q1** I've never been able to establish a (pairing) connection between the watch and phone.

Are you using a supported phone model?

Check if the phone model and its operating system are supported by the watch.

For information about supported phone models, visit the CASIO Website.

[https://world.casio.com/os\\_mobile/wat/](https://world.casio.com/os_mobile/wat/)

Is CASIO WATCHES installed on your phone?

The CASIO WATCHES needs to be installed in order to connect with the watch.

① [Installing required app on your phone](#)

Are your phone's Bluetooth settings configured correctly?

Configure the phone's Bluetooth settings. For details about setting procedures, see your phone documentation.

#### iPhone Users

- "Settings" → "Bluetooth" → On
- "Settings" → "Privacy" → "Bluetooth Sharing" → "CASIO WATCHES" → On

#### Android Users

- Enable Bluetooth.

Other than the above.

Some phones need to have BT Smart disabled to use CASIO WATCHES. For details about setting procedures, see your phone documentation.

On the Home Screen, tap: "Menu" → "Settings" → "Bluetooth" → "Menu" → "BT Smart settings" → "Disable".

**Q2** I can't establish a connection (pairing) between the watch and a newly purchased phone.

To connect with a newly purchased phone, you will need to perform the pairing operation again with the new phone. Use CASIO WATCHES to delete the pairing information from your current (old) phone, and then pair the watch with the new phone.


[If you purchase another phone](#)

## I can't reconnect the watch and phone.

**Q1** The watch will not re-connect with the phone after they are disconnected.

Is CASIO WATCHES running on your phone?

Check if CASIO WATCHES is running on the phone. On the phone's Home Screen, tap the CASIO WATCHES icon. Then on the watch, hold down the CONNECT button (B) for about 1.5 seconds.



Have you tried turning your phone off and then back on again?

Turn the phone off and then back on, and then tap the CASIO WATCHES icon. Next, on the watch, hold down the CONNECT button (B) for about 1.5 seconds.



**Q2** I can't connect while my phone is in the Airplane Mode.

Connection with the watch is not possible while the phone is in the Airplane Mode. After exiting the phone's Airplane Mode, go to its Home Screen and tap the "CASIO WATCHES" icon. Then on the watch, hold down the CONNECT button (B) for about 1.5 seconds.



**Q3** I changed the phone's Bluetooth from enabled to disabled, and now I can't connect anymore.

On the phone, disable and then re-enable Bluetooth, and then go to the Home Screen and tap the "CASIO WATCHES" icon. Next, on the watch, hold down the CONNECT button (B) for about 1.5 seconds.



**Q4** I can't connect after turning off the phone.

Turn on the phone and tap the CASIO WATCHES icon. Then on the watch, hold down the CONNECT button (B) for about 1.5 seconds.




## Phone-Watch Connection

**Q1** I can't establish a connection between the phone and watch.

Have you tried turning your phone off and then back on again?

Turn the phone off and then back on, and then tap the CASIO WATCHES icon. Next, on the watch, hold down the CONNECT button (B) for about 1.5 seconds.



Has the watch been re-paired with the phone?

After unpairing the watch and phone, re-pair them again.

[Unpairing](#)

If you are unable to establish a connection...

Delete the pairing information from the watch, and then re-pair the watch and phone.

[See the Note under "Unpairing".](#)

## Changing to a Different Phone Model

**Q1** Connecting the current watch to another phone.

Clear pairing information from the watch you are currently using, and then pair with another phone.

[If you purchase another phone](#)

## Phone Finder

**Q1** Phone Finder does not work.

Are the phone and watch disconnected?

Phone Finder does not work during Bluetooth connection.

Is CASIO WATCHES running on your phone?

Phone Finder will not work unless CASIO WATCHES is running. On the Home Screen, tap the CASIO WATCHES icon.

Other than the above.

If the phone does not respond after a few seconds, it could mean that the phone is located too far from the watch. Change to a different location and try again.

**Q2** It takes some time before the phone responds.

The phone will emit a tone when a connection is established with the watch, which takes a few seconds.

**Q3** The phone cannot be found even when it is close to the watch.

Since communication is performed using radio waves, the watch may not be able to find the phone even if it is within two meters. Certain environments may make the allowable communication range very short.

## Auto Time Adjustment

**Q1** When does the watch sync its time setting with the phone?

The watch will connect with the phone and perform auto time adjustment at around 5:00 a.m., 11:00 a.m., 5:00 p.m. and 11:00 p.m. The connection is automatically terminated after auto time adjustment is complete.

**Q2** The watch time setting is not adjusted when an auto adjustment time is reached.

Is auto time correction not being performed according to its normal schedule?

Note that auto time adjustment is not performed for 24 hours after swapping of the Home Time and World Time, or after the time setting is adjusted manually on the watch. Auto time adjustment will resume 24 hours after either of the above operations is performed.

Is auto time adjustment enabled?

Auto time adjustment will not be performed at the scheduled times unless it is enabled. Establish a connection between the watch and phone, and then use CASIO WATCHES to enable auto time adjustment.

[Using the Watch in a Medical Facility or Aircraft](#)

**Q3** Time is not displayed correctly.

The phone's time setting may not be correct.

① Correct the phone's time setting.

### iPhone Users

- "Settings" → "Privacy" → Turn on "Location Services" → "System Services" → Turn on "Setting Time Zone".

### Android Users

- Refer to your phone's user documentation.

② Establish a connection between the watch and phone, and correct the time setting.

[Auto Time Adjustment](#)

## World Time

**Q1** The time for a World Time City is not correct.

The summer time start date and time, end date and time, or other rules were changed by authorities.

## Hand Movement and Indications

**Q1** Why can't I perform any button operations while high-speed hand movement is in progress?

Button operations are disabled while high-speed hand movement is in progress after a watch setting is changed, etc. Wait until the hands stop moving before performing button operations.

**Q2** The second hand is jumping at two-second intervals.

Battery power is low. Keep the watch exposed to light until it recharges sufficiently.

[Charging the Watch](#)

**Q3** All hands are stopped at 12 o'clock and buttons do not work.

The battery is dead. Keep the watch exposed to light until the battery recharges sufficiently.

[Charging the Watch](#)

**Q4** The hands suddenly start moving at high speed.

This is due to one of the reasons below, and does not indicate malfunction. Simply wait until normal hand movement resumes.

- The watch is recovering from a power saving state. [Power Saving](#)
- Watch is connected with a phone to correct its time setting. [Auto Time Adjustment](#)

**Q5** Hands are stopped and buttons do not work.

The watch is in the charge recovery mode. Wait until the recovery process is complete (for about 15 minutes). The watch will recover more quickly if you place it in a brightly lit location.

**Q6** Hands and the day indicator are out of alignment.

Strong magnetism or impact may cause the hands of the watch to go out of alignment. Use CASIO WATCHES to correct hand alignment.

[🔗 Correcting Hand Alignment](#)

**Q7** The time setting is correct, but the day indicator is between days.

The day is in the process of changing. For information about how the day changes, see the section below.

[🔗 Hands and the Day Indicator](#)

## Crown Operations

**Q1** Nothing happens when I rotate the crown.

Leaving the crown pulled out for more than nine minutes without performing any operation will automatically disable crown operation. Push the crown back in to its normal position and then pull it out again.

[🔗 Using the Crown](#)

**Q2** Crown operation does not work.

Crown operation is disabled while high-speed hand movement is in progress after a watch setting is changed, etc. Wait until the hands stop moving before performing crown operations.

## Charging

**Q1** The watch does not work even though it is exposed to light.

The watch stops operating whenever the battery goes dead. Keep the watch exposed to light until it recharges sufficiently.

[🔗 Solar Charging](#)