

DST Setting Module : 5441

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode from any other mode, hold down (D) button for about two seconds.

1. A black G-Shock watch with a digital display showing 12:00. A pink circle with the letter 'A' is overlaid on the left side of the watch. A red arrow points from the text 'ADJ' to the upper display area of the watch.

Hold down (A) button until ADJ appears in the upper display.

2. A black G-Shock watch with a digital display showing 12:00. A pink circle with the letter 'A' is overlaid on the left side of the watch. A red arrow points from the text 'City Code' to the upper display area of the watch, which now shows 'NYC'.

When you release the button, City Code will be flashing in the upper display.

3. A black G-Shock watch with a digital display showing 12:00. A pink circle with the letter 'D' is overlaid on the left side of the watch.

Press (D) button once.

4.



DST indicator and OFF/ON.

DST indicator and the DST setting (ON or OFF) will appear in the upper display .

5.



Press (E) button to toggle ON and OFF.

6.



Press (A) button to exit the setting screen.