




CITIZEN®





Eco-Drive®

Vertical line on the left side of the page.














1


2



















				





Setting the time

Make sure that the watch is not wet before operating the crown.



1 Pull the crown out to position **2 as the second hand points to 0 seconds.**

The watch stops and the power reserve indication hand moves to the reference position.


2 Rotate the crown to set the time.

- Pay attention to whether the time set is AM or PM.
- Date indication starts to change as the setting passes 10PM. Rotating the crown counter-clockwise does not turn back the date indication.

3 Push the crown in to position in **0 accordance with a reliable time source to finish the procedure.**


1


0



















	0	
	0	





















--

CE

