

CITIZEN®

ManualsLib.com






ManualsLib.com







ManualsLib.com






ManualsLib.com









ManualsLib.com




ManualsLib.com







ManualsLib.com






< Display in meters >



< Display in feet >



ManualsLib.com






< Display in meter >




Display




< Display in feet >



Display




ManualsLib.com






Minutes



ManualsLib.com

< Display in meters >



< Display in feet >




Minutes

Seconds




[Before diving]



Set the alarm depth so that alarm automatically sounds when the diver reaches that depth.



Set the alarm time so that alarm automatically sounds when the diver stays in the water for that period of time.

[After diving]




The maximum depth is automatically recorded and displayed for each dive.

The dive time is automatically recorded and displayed for each dive.





ManualsLib.com




The dive time is displayed when the **R** button is pushed in the depth measurement display.

If diving when the depth meter is displayed, the diving depth will be displayed.

* If diving when the depth measurement display is on, the current dive time is added to the previous diving time.



ManualsLib.com



N.D. LIMITS			
DEPTH m	N.D. TIME	NO. DECOMPRESSION LIMITS	
(No decompression limits)			
12	200	30	25
15	100	33	20
18	60	36	15
21	60	30	10
24	40	42	10
27	30	45	5

DEPTH m, N.D. TIME
(Depth meter)
(No decompression time)



DISPLAY FUNCTION

Digital Display

ManualsLib.com



-
-
-
-
-
-
-
-
-
-

ManualsLib.com

-
-
-
-