

SEIKO WATCH CORPORATION
Copyright©2022 by SEIKO WATCH CORPORATION

SEIKO




العربية
简体中文 繁體中文 한국어 ไทย






HOW TO USE



Names of the parts and their functions

■ 6R20 / 6R21



- ① Minute hand
- ② Hour hand
- ③ Power reserve indicator
- ④ Seconds hand
- ⑤ Day hand (day of the week)
- ⑥ Crown
 - Normal position (not locked): Wind up the watch (hand-wound)
 - First click position: Date and day of the week setting
 - Second click position: Time setting
- ⑦ Date hand

* The position and design of the display may vary depending on the model.
 * The direction of the power reserve indicator is different depending on the model.

■ 6R24



- ① Minute hand
- ② Hour hand
- ③ Power reserve indicator
- ④ Seconds hand
- ⑤ Date hand
- ⑥ Day hand (day of the week)
- ⑦ Crown
 - Normal position (not locked): Wind up the watch (hand-wound)
 - First click position: Date and day of the week setting
 - Second click position: Time setting

* The position and design of the display may vary depending on the model.

■ 6R27




- ① Minute hand
- ② Hour hand
- ③ Power reserve indicator
- ④ Seconds hand
- ⑤ Date hand
- ⑥ Crown
 - Normal position (not locked): Wind up the watch (hand-wound)
 - First click position: Date setting
 - Second click position: Time setting







* The position and design of the display may vary depending on the model.


Crown


There are two types of crowns, a normal crown and a screw down crown. Please check the type of the crown of your watch.




* By locking the crown by screw, a screw down crown can prevent malfunction and increase water resistance.
 * Be careful not to screw the crown in by force as it may damage the slots of the crown.

















		⚠
()		




	⚠
CI	
CI	











TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH