


PULSAR

ENGLISH



English



English




English



English

English



English

English




English

English



The first 100 lap and split times are automatically stored in memory.



English

English



- The minute digits start flashing.
- ▼
- Set the flashing digits. (Increasing digits)
- Set the flashing digits. (Decreasing digits)
- ▼
-

English

English



English

English




-
- ▼
-
- ▼
- Set the flashing digits. (Increasing digits)
- Set the flashing digits. (Decreasing digits)
- ▼
-



English

English



English

English

English

English

-
- When the seconds count any number from "30" to "59" and button B or C is



English

The battery life may be less than 3 years if the alarm sounds more than 20 seconds

When the battery voltage becomes low, the battery mark starts flashing on the dis



fire. The battery may burst, become very hot or catch fire.



* Before using the water resistance 5, 10, 15 or 20 bar watch in water, be sure the

* When taking a shower with the water resistance 5 bar watch, or taking a bath with the water resistance 10, 15 or 20 bar watch, be sure to observe the following:

- Do not operate the crown when the watch is wet with soapy water or shampoo.
- If the watch is left in warm water, a slight time loss or gain may be caused. This

NOTE:



English















English