

CITIZEN®

Model No. CTZ-A8121 * 19 Cal No. E31 *

- INSTRUCTION MANUAL
- MANUEL D'INSTRUCTIONS
- MANUAL DE INSTRUCCIONES



Eco-Drive

CTZ-A8121

Eco-Drive

ManualsLib.com






ManualsLib.com

ManualsLib.com




ManualsLib.com





■ How to use the screw down crown




To release the crown

Turn the crown to the left until it pops out slightly.

To lock again

Tighten the crown completely by pressing and turning it to right.

■ When leaving the watch unused for an extended period of time



Pull out the crown to position **2**.

All hands stop moving and the battery power is saved.

- The date will change to the following day every 24 hours once you have pulled out the crown to position **2**.






ManualsLib.com





■ When the battery becomes short of power—Insufficient charge warning function

When the battery becomes short of power, the second hand moves once every two seconds—insufficient charge warning function. Charge the battery by exposing the dial to light.



- After the battery is charged for a while, the second hand will move normally.
- If you have not charged the battery for three days or more since the warning movement began, the battery will run out and the watch will stop.

NOTICE:

You cannot check or adjust the settings while the warning movement continues, though you can see the time.






	ManualsLib.com		

--	--

ManualsLib.com





2






ManualsLib.com



ManualsLib.com



	05
	M 2
	LY 1

ManualsLib.com








1



ManualsLib.com






		L.Y. 0
		L.Y. 2

ManualsLib.com

ManualsLib.com






ManualsLib.com

		M0 2
		M1 2



		M0 9
		M1 1

ManualsLib.com





ManualsLib.com

		08
		31



		05
		30



ManualsLib.com

ManualsLib.com

ManualsLib.com

ManualsLib.com



ManualsLib.com



ManualsLib.com

ManualsLib.com

ManualsLib.com



ManualsLib.com



ManualsLib.com




0


ManualsLib.com




ManualsLib.com





1





ManualsLib.com





2

ManualsLib.com

0



0

ManualsLib.com



	*

ManualsLib.com

ManualsLib.com

ManualsLib.com

ManualsLib.com
CITIZEN®

CTZ-A8121