

DST Setting / Module : 5463

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down (B) for about two seconds.

1.



In the Timekeeping Mode, pull out the crown.

2.



City will flash on the display. Second hand will indicate the city code.

3.



Press (B) to display the DST setting screen.

4.



Rotate the crown to toggle the DST settings as follows.

▶ **OFF** → **ON** → **AUTO**

5.



Push the crown back in.