



**CITIZEN**<sup>®</sup>

Eco-Drive. A revolutionary watch.







[Normal time display]

[Insufficient charge warning display]

[Stop warning display]




If insufficiently charged




If charged

If insufficient charge continues for a further about 5 days



If charging is insufficient

[Hands setting warning display]



If sufficiently charged and time is set

If charged








—










—











Pressing button (A) to repeat the chronograph start and stop cycle.

