



CITIZEN®



INSTRUCTION MANUAL














The diagram shows a cross-section of a ship's hull. At the top, there is a curved structure representing the deck or hull plating, with a small circle containing the number '08' below it. Below this is a banner with the text 'N.D.LIMITS'. Underneath the banner is a table with four columns: 'DEPTH.M', 'N.D.', 'TIME', and an unlabeled column. The table contains the following data:

DEPTH.M	N.D.	TIME	
12	200	30	25
15	100	33	20
18	60	36	15
21	50	39	10
24	40	42	10
27	30	45	5