





ManualsLib.com




Name		Time Mode	Calendar Mode	Alarm 1/2 Mode	Chronograph Mode	Timer Mode	Zone Setting Mode
A: Button A	Press once	EL lamp turns on		ON/OFF switch	Start/stop	Start/stop	EL lamp turns on
	Press for 2 seconds or more			Alarm sound monitor	—	—	
B: Button B	Press once	Switch the displayed city	Switch the displayed city	Switch the displayed city	Split/reset	Set time adjustment	Switch the displayed city
	Press for 2 seconds or more	To time adjustment mode	To calendar adjustment mode	To alarm setting mode	—	Set time quick adjustment	To zone setting mode
M: Button M	Press	To <CAL> mode	To <AL1> mode	To <CHR> mode	To <TMR> mode	To <SET> mode	To <TME> mode
a : Mode display		TME	CAL	AL1/AL2	CHR	TMR	SET
b : Digital display [1]		Hours, minutes, seconds	Month, date	Hours, minutes or OFF	Minutes, seconds, 1/100 seconds	Remaining time (Minutes, seconds)	Hours, minutes, seconds
c : Digital display [2]		City name	Day or name of cities	City name	Hours	Set time (minutes)	City name
d : Crown				Used for analog time setting			
e : Hour hand				Always time (hours) display			
f : Minute hand				Always time (minutes) display			
g : Second hand				Always time (seconds) display			



Display Mode	
TME	Time
CAL	Calendar
AL1	Alarm 1
AL2	Alarm 2
CHR	Chronograph
TMR	Timer
SET	Zone Setting






ManualsLib.com




Position for time adjustment

No.	Indication	City	Time difference	Summer-time	No.	Indication	City	Time difference	Summer-time
1	UTC	Universal time coordinated	±0	—	17	TYO	Tokyo	+9	×
2	LON	London	±0	○	18	SYD	Sydney	+10	○
3	PAR	Paris	+1	○	19	NOU	Nouméa	+11	×
4	ROM	Rome	+1	○	20	AKL	Auckland	+12	○
5	CAI	Cairo	+2	○	21	HNL	Honolulu	-10	×
6	IST	Istanbul	+2	○	22	ANC	Anchorage	-9	○
7	MOW	Moscow	+3	○	23	LAX	Los Angeles	-8	○
8	KWI	Kuwait	+3	×	24	DEN	Denver	-7	○
9	DXB	Dubai	+4	×	25	CHI	Chicago	-6	○
10	KHI	Karachi	+5	×	26	MEX	Mexico City	-6	×
11	DEL	New Delhi	+5.5	×	27	NYC	New York	-5	○
12	DAC	Dacca	+6	×	28	YUL	Montreal	-5	○
13	BKK	Bangkok	+7	×	29	CCS	Caracas	-4	×
14	SIN	Singapore	+8	×	30	RIO	Rio de Janeiro	-3	○
15	HKG	Hong Kong	+8	×	31	BUE	Buenos Aires	-3	×
16	PEK	Beijing	+8	×					


<Normal time display>



<Normal alarm display>





<Normal calendar display>





ManualsLib.com




<Chronograph reset display>







※ 1 Timer restart function





※ 1 : After 10 seconds, automatically returns to the measuring display.

ManualsLib.com




<Timer set display>






ManualsLib.com



**Name of Scale • Marking**



▲

→

→

→

▲

▲

▲

→

→

→

ManualsLib.com

▲

▲

▲

→

→

→


▲

▲

▲



[ManualsLib.com](http://ManualsLib.com)



**ManualsLib.com**