




Part Name	Time mode	Calendar mode	Alarm mode
[A] button	Normal mode Adjustment mode	City name change (Downward)	
	Normal mode	Summertime change Hours, Min. Sec. (±2hour)	Month, Date, Day, Year ON/OFF setting Hours, Minutes
[B] button	Normal mode Adjustment mode	City name change (Upward)	
	Normal mode	Adjustment digit change	
[M] button	Normal mode Adjustment mode	Changes to the next mode	
	Adjustment mode	Returns to the normal display	
[1]	Digital display-1	City name CHARGE (insufficient charge indication)	city name
[2]	Digital display-2	Hours, Min. Sec. (AM/PM) SUM (Summertime set) Mode Indication (TME)	Hours, Minutes, (AM/PM) ON/OFF, SUM (Summertime set) Mode Indication (CAL) set Mode Indication (ALM)
[3]	Crown	Analog time setting	
[4]	Hour hand	Always indicates hours	
[5]	Minute hand	Always indicates minutes	
[6]	Second hand	Always indicates seconds	



Chronograph mode	Timer mode	Zone set mode
start/stop	start/stop	City name change (Down) City indication set (ON/OFF)
split/reset	Timer set/flyback	City name change (Up) Adjustment digit change (Zone set, Sum. time)
Changes to the next mode		
Time measurement (Hours)	Set time (Minutes)	City name
Time measurement (Min. Sec. /10 sec.) Mode Indication (CLR)	Remaining time (Min. Sec. /10 sec.) Mode Indication (TMR)	Hours, Min., Sec. (AM/PM) SUM (Summertime set) Mode Indication (Set)
Analog time setting		
Always indicates hours		
Always indicates minutes		
Always indicates seconds		



Manuals







ManualsLib.com










ManualsLib.com





Indication		Water related use		
Dial	Caseback	Specification	 Washing face or getting wet in the rain that is, when splashed over the watch and no water pressure is applied to it.	 Swimming and general washing work (kitchen work/car washing etc.)
—	WATER RESIST	3 bar water resistant watch	OK	NO
WATER RESISTANT (5bar)	WATER RESIST	5 bar water resistant watch	OK	OK
WATER RESISTANT (10—20bar)	WATER RESIST	10/20 bar water resistant watch	OK	OK

"WATER RESISTANT" may sometimes be abbreviated "WATER RESIST"

 Water sports and skin diving (without air tank)	 Scuba diving (Diving with air tank)	 Pulling the crown out when the watch is wet.
NO	NO	NO
NO	NO	NO
OK	NO	NO

● Always set the crown in the normal position.

ManualsLib.com

±

ManualsLib.com

ManualsLib.com
