

# User's Guide 3229/3421/3489

CASIO®

## ENGLISH

Congratulations upon your selection of this CASIO watch.

### Important!

- This manual provides a brief overview of your watch.

For a full Operation Guide and Q&A information about this product, go to the website below.

<https://world.casio.com/manual/wat/>




E

E-1

## Configuring Time and Date Settings

### To set the time and date

- Press (A) while in the Timekeeping Mode. The seconds digits flash on the display because they are selected.
- Press (C) to change the selection in the following sequence.




E-2

E-3

## Mode Selection and Operations

- Press (C) to change the mode.

- After you perform an operation in any mode, pressing (C) returns to the Timekeeping Mode.



E-4

E-5

## Specifications

**Accuracy at normal temperature:** ±15 seconds a month

**Timekeeping:** Hour, minutes, seconds, pm (PM), month, day, the day of the week  
Time system: Switchable between 12-hour and 24-hour formats  
Calendar system: Auto-calendar pre-programmed from the year 2000 to 2099

**Alarm:** Multi-function alarm, hourly time signal

### Countdown Timer

Measuring unit: 1 second  
Input range: from 1 second to 24 hours  
Other: Auto-repeat function

### Stopwatch

Measuring units: 1/100 second (for the first 60 minutes)  
1 second (after 60 minutes)  
Measuring capacity: 23 hours, 59 minutes, 59 seconds  
Measuring modes: Elapsed time, split time and two finishes

**Illumination:** EL (electro-luminescent) backlight

### Battery:

Modules 3229/3421: One lithium battery (Type: CR2016)

Approximately 2 years on type CR2016 (Assuming 3.5 seconds display illumination operation and 20 seconds alarm operation per day, Flash Alert enabled)

Module 3489: One lithium battery (Type: CR1616)

Approximately 2 years on type CR1616 (Assuming 3.5 seconds display illumination operation and 20 seconds alarm operation per day, Flash Alert enabled)

Note: Frequent use of the backlight shortens the battery life noted above.

Specifications are subject to change without notice.

E-6

E-7