

["TIME" mode]

[Cal. N944]

Stopwatch
1/10 second hand

Center hand
(stopwatch/timer
second hand)

Minute hand

Hour hand

Normal position

24-hour hand

First click

Second click

Date


Crown

Dual time hand

Center hand
(date indicator)

Mode indicator






HAND MODE	Hour hand	Minute hand	24-hour hand	Dual time hand (24 hour)	Center hand		Stopwatch 1/10 sec. hand
					Stopwatch second	Date indicator	
TIME	Current time			Dual time (24 hour)	N/F	Date	N/F
	Hour	Minute	24-hour				
TIME•))	Current time			Dual time (24 hour)	N/F	Date	N/F
	Hour	Minute	24-hour				
(((• Set	Alarm time			*1	N/F	Date	N/F
	Hour	Minute	24-hour				
→∅←	"0" position (12 O'clock position)			N/F	"0" position	N/F	"0" position
TIMER	N/F	Timer minute	N/F	N/F	Timer second	N/F	*2
CHRONO.	Stopwatch			N/F	Stopwatch second	N/F	Stopwatch 1/10 sec.
	Hour	Minute	Hour				


MODE	Crown position							
	Crown	Normal		Crown	First Click		Second Click	
		Button			Button		Button	
		"A"	"B"		"A"	"B"	"A"	"B"
TIME	Mode Change	N/F	N/F	Dual time Setting	Calendar setting		Time setting	
TIME•)))	Mode Change	Alarm test by pressing "A" and "B" simultaneously		Dual time Setting	Calendar setting		Time setting	
(((• Set	Mode Change	N/F	N/F	*	N/F	N/F	Alarm setting	
→⇄←	Mode Change	N/F	N/F	*	Adjusting stopwatch 1/10 sec. and stopwatch sec.		Adjusting hour, minute and 24-hour hands.	
TIMER	Mode Change		Recall of preset time	*	N/F	N/F	Timer setting	
		Start Stop	Reset					
CHRONO.	Mode Change	Start Stop	Split Reset	+	N/F	N/F	N/F	N/F








[Cal. N944]



[Cal. N945]



Date indicator

A First click

Crown


Date


Mode indicator


B



A

B









Timer second hand

1/10 second hand

Second click

Crown

Mode indicator

Minute hand

Mode indicator

Minute hand

