


CITIZEN®



INSTRUCTION MANUAL




Eco-Drive®














When the watch is exposed to light, the Quick Start Function will begin operating and the second hand will start moving. The correct time can be set once the watch is fully charged.

















CE

