




ManualsLib.com

ManualsLib.com

歡迎你購買精工 機亞動力鋸[®]。為了更好地使用精工動力鋸[®]，請你在使用前詳細閱讀本說明手冊，並把說明手冊妥善保管，以備隨時用於參考。





ManualsLib.com





ManualsLib.com






★★



ManualsLib.com








ManualsLib.com





ManualsLib.com



ManualsLib.com



Major cities in respective time zones	Time difference with GMT (UTC)
Fiji	-11 hours
Honolulu	-10 hours
Anchorage ★	-9 hours
Los Angeles ★, San Francisco ★	-8 hours
Denver ★, Edmonton ★	-7 hours
Chicago ★, Mexico City ★	-6 hours
New York ★, Washington ★, Montreal ★	-5 hours
Santiago ★	-4 hours
Rio de Janeiro ★	-3 hours
Azores ★	-1 hour
London ★, Casablanca	0 hour

Paris ★, Rome★, Amsterdam★	+1 hour
Cairo ★, Athens★, Istanbul★	+2 hours
Jeddah, Mecca, Nairobi	+3 hours
Dubai	+4 hours
Karachi, Tashkent★	+5 hours
Dhaka	+6 hours
Bangkok, Jakarta	+7 hours
Hong Kong, Manila, Beijing, Singapore	+8 hours
Tokyo, Seoul, Pyongyang	+9 hours
Sydney ★, Guam, Khabarovsk★	+10 hours
Nouméa, Solomon Islands	+11 hours
Wellington ★, Fiji islands, Auckland★	+12 hours

* Cities marked with "★" use daylight saving time.

* The time differences and use of daylight saving time in each city are subject to change according to the governments of the respective countries or regions.

WORLD TIME DISPLAY (ONLY FOR MODELS WITH THE ROTATING BEZEL FOR WORLD TIME DISPLAY)

- By using the 24-hour hand and rotating bezel, the times of 22 cities in different time zones throughout the world can be read from the dial.



Turn the rotating bezel so that the city mark corresponding to the area whose time has been set in the "How to set the time" aligns with the 24-hour hand.

▼ Each city mark on the bezel indicates the time of the city or area it represents. Read the times in the various cities, referring to the 24-hour marks on the dial.

ManualsLib.com



ManualsLib.com



ManualsLib.com



ManualsLib.com

ManualsLib.com