

SEIKO
SINCE 1881

SEIKO



العربية

简体中文 繁體中文 한국어 ไทย



[REDACTED]

[REDACTED]

[REDACTED]



A large rounded rectangular box with a black border, divided into three horizontal sections. The top section is filled with a solid grey color. The middle and bottom sections are white. The box is empty of text or other content.









Names of the parts and their functions

1

HOW TO USE

■ 4R35



① Minute hand

② Hour hand

③ Seconds hand

④ Date

⑤ Crown

- Normal position (not locked): Wind up the watch (hand-wound)
- First click position: Date setting
- Second click position: Time setting

* The position and design of the display may vary depending on the model.

■ 4R36



① Minute hand

② Hour hand

③ Seconds hand

④ Date and day of the week

⑤ Crown

- Normal position (not locked): Wind up the watch (hand-wound)
- First click position: Date and day of the week setting
- Second click position: Time setting

* The position and design of the display may vary depending on the model.

■ 4R37



① 24-hour hand

② Hour hand

③ Seconds hand

④ Minute hand

⑤ Date

⑥ Crown

- Normal position (not locked): Wind up the watch (hand-wound)
- First click position: Date setting
- Second click position: Time setting

* The position and design of the display may vary depending on the model.

■ 4R38 / 4R71 / 4R72



① Minute hand

② Hour hand

③ Seconds hand

④ Crown

- Normal position (not locked): Wind up the watch (hand-wound)
- First click position: Time setting

* The position and design of the display may vary depending on the model.

■ 4R39



① 24-hour hand

② Hour hand

③ Seconds hand


④ Minute hand

⑤ Crown

- Normal position (not locked): Wind up the watch (hand-wound)
- First click position: Time setting

* The position and design of the display may vary depending on the model.

HOW TO USE















































HOW TO USE


















LL
JL








TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH




TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH







TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH












TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH








TO PRESERVE THE QUALITY OF YOUR WATCH




TO PRESERVE THE QUALITY OF YOUR WATCH








TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH



TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH







TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH





TO PRESERVE THE QUALITY OF YOUR WATCH

TO PRESERVE THE QUALITY OF YOUR WATCH

SEIKO WATCH CORPORATION

Copyright©2022 by SEIKO WATCH CORPORATION

Printed in Japan