




## Radio Wave Reception

### 5. For Best Reception

There are three kinds of reception: automatic reception, on demand reception, and recovery automatic reception. When the radio wave has been properly received, your watch will automatically adjust the time. When reception is complete, each of the hands will move either clockwise or counterclockwise to the received time.

Remove the watch from your wrist and place on a stable surface near a window where the radio wave can be easily received, pointing the 9:00 position in the direction of the radio wave transmitter. Do not move the watch during reception.



- Reception may be difficult due to the surroundings or metal shielding. When inside a building, place the watch as close to a window as possible for good reception.
- Radio wave reception may be difficult during the hours around sunrise and sunset. Avoid attempting to receive radio waves during these times.

### 6. Poor Reception Areas

It may be difficult to properly receive the radio waves under certain environmental conditions or in areas susceptible to radio noise.



- ◆ Extremely hot or cold locations



- ◆ Near high-tension electrical lines, railway overhead wires or communication facilities



- ◆ Inside vehicles, including cars, trains and aero planes



- ◆ Near TVs, refrigerators, computers, fax machines and other electrical equipment or office appliances



- ◆ Near cellular phones that are in use



- ◆ Inside reinforced concrete buildings  
Between tall buildings or mountains, or underground





