

HYPERRAP™

Original Disc-Scratching Watch



Instruction Manual

HyperRap is:

- A watch that designed for the youth who is crazy about Pop and Dance Music and wanted to be a professional Disc Jockey who can create their own original music by Dragging Music disc in a creative and professional way.
- A watch which can show you the time, date and day of the week in a very "POP Music" style. It also has the alarm function, which will alarm with Pop music and real human voice!
- HyperRap is the first watch in the world which the main operation is based on a rotateable disc. It makes all the operation simple and direct!
- With a distorted spherical LCD dot matrix display. All the images that comes out from the watch will give you a very Cyber feeling!
- A superior watch which has a lot of sound, games and animations. Hence, battery life may be shorter than other electronic digital watch and electronic games.

HyperRap is not:

- Water-resistant.
- Shockproof.
- Vibration resistant

Basically HyperRap are divided into two modes: Time display mode and DJ game mode.

Time display mode: Showing the current time



- When you want to see the current time, simply drag the disc in any direction. An animation of a dancer will pullout the digit and the current time will be gradually scrolled from right to left. Each time will have different dance to pull out the time (there will be six styles in total).
- The current time will hold for you to see for about 6 seconds. During that time, if you want to see the date and the day of the week, simply drag the disc in any direction.
- The information of the date, day of the week and the alarm will scroll from right to left and show for each time you drag the disc.
- You can change the direction of the scrolling in any status of scrolling, either they are just start the scroll from the right, or they are close to the end, you can still adjust the direction of scrolling from dragging the disc in the different direction.
- After the entire key input over 6 seconds, a dancing animation will show and the screen will turn off. Each time will have different dancing animation to close the screen (there will be six styles in total).

Time display mode:

Adjust the time, date and day of the week



- If you want to adjust the current time, you can first press the **Time Adjust Key** (on the top left-hand corner), then the current time will show and the first digit will become a dancer.
- You can start adjust the digit by dragging the disc in different direction to increase or decrease the digit.

When the correct digit turns out, press the **Time Adjust Key** to confirm.

- The dancer animation will jump to the next digit, and you can adjust the digit by dragging the disc again. All the digits will be scrolling up and down which looks similar to a slot machine. After finish adjusts the time (with AM/PM), the current date will display.
- You also need to adjust the date similar to adjusting the time. If it is correct, simply press the **Time Adjust Key** through digit after digit to confirm. The final step is to correct the year, which this is affecting the day of the week. Simply drag the disc to adjust the year. Press the **Time Adjust Key** to confirm.

Time display mode:

Set the alarm



- To set the alarm, you can drag the disc in the normal time display mode until the word "ALARM" appears, then press the **Time Adjust Key**.
- Set your desire alarm time based on the same procedure as "adjust the time", and either a "ON" or "OFF" dancer will appear.
- You can drag the disc to select the alarm are "ON" or "OFF". A dancing animation with a sound effect will follow when you select the alarm "ON". Press the **Time Adjust Key** to confirm. The watch will then split from the center and go back to the time display screen.

SLYTRONIC

WRISTWATCH
GAMES
DATABASE

DJ Game mode:



• To go into the DJ Games mode, press the **Game Key**. There are two different games in this mode: *Practice Mode* and *DJ Challenge mode*.



• After you press the **Game Key**, the whole screen will flash and split from the middle of the screen, then a single dancer will appear. It stands for the *Practice mode*.



• You can select the game by dragging the disc in different direction. Then another screen with two dancers dancing side by side will appear. It stands for the *DJ Challenge mode*.

DJ Game mode: Practice Mode



• The aim of this game mode is to provide an environment for the player to drag freely and to compose his own version of "DJ Mix". To enter the game, press the **Mode Key** when you see the single dancer appear. The song will play repeatedly and a series of dancing animation will show.

• Player can drag the disc freely, and some disc dragging sound will play and "jammed in" the song, as well as some MTV type animations will display to enhance the feeling of disco music video.

• The song will last for 40 second. After that, player can start the game again by pressing the **Game Key** or drag the disc and select the icon of "*DJ Challenge*" game.

DJ Game mode: DJ Challenge Mode



• The aim of this game is to test your disc dragging skill and the sense of rhythm. To select this game, drag the disc to see the DJ challenge icon, and select it by presses the **Mode Key**.



• In this game, the screen will be split into two halves. On the left hand side, it will show the animated dancer as well as the countdown to start the game. On the right hand side, there will be two types of bar, in a different length, which represent different direction of disc dragging, will be fallen from top to bottom. Drag clockwise to hit the long bar and drag anti-clockwise to hit the short bar.

• Basically those bars are score by the "DJ" inside the watch. It has mark in the middle- low part of the screen. You are required to hit the bar by dragging the disc on the right time and direction when the bar pass through the mark. It also helps you to compose a "DJ Mix" which are suggested by the watch.

• If you can miss to hit the bar in the right time and right direction, a success animation will appear after the games. If not, fail animation will appear.

1200