


## Getting Acquainted

Congratulations upon your selection of this CASIO watch. To get the most out of your purchase, be sure to carefully read this manual and keep it on hand for later reference when necessary.

**Expose the watch to bright light to charge its battery before using it.**  
 You can use this watch even as its battery is being charged by exposure to bright light.  
 • Be sure to read "Battery" of this manual for important information you need to know when exposing the watch to bright light.

If the display of the watch is blank...



If the **SLEEP** indicator is on the display, it means that the display is blank because the watch's Power Saving function has turned off the display to conserve power. Power Saving automatically turns off the display and puts the watch into a sleep state whenever your watch is left for a certain period where it is dark.

- The initial factory default setting is Power Saving on.
- The watch recovers from the sleep state if you move it to a well-lit area\*, if you press any button, or if you angle the watch towards your face for reading.

\*It can take up to five seconds for the display to turn on.  
 • See "Power Saving Function" for more information.

## General Guide

- Press (C) to change from mode to mode.
- In any mode, press (B) to illuminate the display.

### Timekeeping Mode



Press (C).

### Countdown Timer Mode



### Alarm Mode




### Dual Time Mode



### Stopwatch Mode




## Timekeeping



Use the Timekeeping Mode to set and view the current time and date.

### To set the time and date

1. In the Timekeeping Mode, hold down (A) until the seconds start to flash, which indicates the setting screen.
2. Press (C) to move the flashing in the sequence shown below to select other settings.




3. When the setting you want to change is flashing, use (D) and (B) to change it as described below.

Setting	Screen	Button Operation
Seconds	10:58:50	Press (D) to reset to 00.
Hour, Minutes	10:58:50	Use (D) (+) and (B) (-) to change the setting.
12/24-Hour Format	12 H	Press (D) to toggle between 12-hour (12H) and 24-hour (24H) timekeeping.
Year, Month, Day	02 6-30	Use (D) (+) and (B) (-) to change the setting.
Power Saving	00	Press (D) to toggle Power Saving on (00) and off (0FF).

4. Press (A) to exit the setting screen.
- See "Power Saving Function" for details about configuring Power Saving settings.
- The 12-hour/24-hour timekeeping format you select in the Timekeeping Mode is applied in all modes.
- The day of the week is automatically displayed in accordance with the date (year, month, and day) settings.

## Countdown Timer



The countdown timer can be set within a range of one minute to 100 hours. An alarm sounds when the countdown reaches zero.

- Countdown timer functions are available in the Countdown Timer Mode, which you enter by pressing (C).

### To set the countdown start time

1. In the Countdown Timer Mode, hold down (A) until the hour setting of the countdown start time starts to flash, which indicates the setting screen.
2. Press (C) to move the flashing between the hour and minute settings.
3. While a setting is flashing, use (D) (+) and (B) (-) to change it.
  - To set the starting value of the countdown time to 100 hours, set 0:00.
4. Press (A) to exit the setting screen.

## About This Manual




- Button operations are indicated using the letters shown in the illustration.
- Each section of this manual provides you with the information you need to perform operations in each mode. Further details and technical information can be found in the "Reference" section.

## To use the countdown timer

- Press (D) while in the Countdown Timer Mode to start the countdown timer.
- When the end of the countdown is reached, the alarm sounds for 10 seconds or until you stop it by pressing any button. The countdown time is automatically reset to its starting value after the alarm stops.
  - Press (D) while a countdown operation is in progress to pause it. Press (D) again to resume the countdown.
  - To completely stop a countdown operation, first pause it (by pressing (D)), and then press (A). This returns the countdown time to its starting value.
  - The countdown timer measurement operation continues even if you exit the Countdown Timer Mode.

## Alarms

### Timekeeping Mode Time



You can set five independent Daily Alarms. When an alarm is turned on, the alarm tone sounds when the alarm time is reached. One of the alarms can be configured as a snooze alarm or a one-time alarm, while the other four are one-time alarms.

- You can also turn on an Hourly Time Signal that causes the watch to beep twice every hour on the hour.
- There are five alarm screens numbered 1 through 5.
- The hourly time signal screen is indicated by 00.
- All of the operations in this section are performed in the Alarm Mode, which you enter by pressing (C).

### To set an alarm time

1. In the Alarm Mode, use (D) to scroll through the alarm screens until the one whose time you want to set is displayed.
- 

- You can configure Alarm 1 as a snooze alarm or a one-time alarm. Alarms 2 through 5 can be used as one-time alarms only.
  - The snooze alarm repeats every five minutes.
2. After you select an alarm, hold down (A) until the hour setting of the alarm time starts to flash. This indicates the setting screen.
  3. Press (C) to move the flashing between the hour and minute settings.
  4. While a setting is flashing, use (D) (+) and (B) (-) to change it.
    - When setting the alarm time using the 12-hour format, take care to set the time correctly as a.m. (no indicator) or p.m. (P indicator).
  5. Press (A) to exit the setting screen.

### Alarm Operation

The alarm sounds at the preset time for about 10 seconds in all modes. In the case of the snooze alarm, the alarm operation is performed a total of seven times, every five minutes, until you turn the alarm off or change it to a one-time alarm.

### Note


- Pressing any button stops the alarm tone operation.
- Performing any one of the following operations during a 5-minute interval between snooze alarms cancels the current snooze alarm operation.
  - Displaying the Timekeeping Mode setting screen
  - Displaying the Alarm 1 setting screen

### To test the alarm

In the Alarm Mode, hold down **(D)** to sound the alarm.


### To turn Alarms 2 through 5 on and off

- In the Alarm Mode, use **(D)** to select a one-time alarm (alarm number 2 through 5).
  - Press **(A)** to toggle the displayed alarm on and off.
- Turning on a one-time alarm (2 through 5) displays the one-time alarm on indicator (ALM) on its screen.
  - The one-time alarm on indicator is displayed in all modes.
  - If any alarm is on, the alarm on indicator is shown on the display in all modes.



### To select the operation of Alarm 1

- In the Alarm Mode, use **(D)** to select Alarm 1.
- Press **(A)** to cycle through the available settings in the sequence shown below.



- The applicable alarm on indicator (ALM or SNZ ALM) is displayed in all modes when an alarm is turned on.
- The SNZ indicator flashes during the 5-minute intervals between alarms.
- Displaying the Alarm 1 setting screen while the snooze alarm is turned on automatically turns off the snooze alarm (making Alarm 1 a one-time alarm).


### To turn the hourly time signal on and off

- In the Alarm Mode, use **(D)** to select the Hourly Time Signal.
  - Press **(A)** to toggle it on and off.
- Turning on the Hourly Time Signal displays the hourly time signal on indicator (SIG) on its screen.
  - The hourly time signal on indicator is displayed in all modes.




## Stopwatch

- The stopwatch lets you measure elapsed time, split times, and two finishes.
- The display range of the stopwatch is 99 hours, 59 minutes, 59.99 seconds.
  - The stopwatch continues to run, restarting from zero after it reaches its limit, until you stop it.
  - The stopwatch measurement operation continues even if you exit the Stopwatch Mode.
  - Exiting the Stopwatch Mode while a split time is frozen on the display clears the split time and returns to elapsed time measurement.
  - All of the operations in this section are performed in the Stopwatch Mode, which you enter by pressing **(C)**.



### To measure times with the stopwatch

#### Elapsed Time



#### Split Time



#### Two Finishes



## Dual Time

- The Dual Time Mode lets you keep track of time in a different time zone.
- The seconds count of the Dual Time is synchronized with the seconds count of the Timekeeping Mode.


### To set the Dual Time

- Press **(C)** to enter the Dual Time Mode.
  - Use **(A)** and **(D)** to set the Dual Time Mode time.
- Each press of **(D)** increases the time setting in 30-minute increments.
  - Pressing **(A)** sets the Dual Time Mode to the same time as the Timekeeping Mode.



## Backlight

- The backlight uses an EL (electro-luminescent) panel that causes the entire display to glow for easy reading in the dark. The watch's auto light switch automatically turns on the backlight when you angle the watch towards your face.
- The auto light switch must be turned on (indicated by the auto light switch on indicator) for it to operate.
  - See "Backlight Precautions" for other important information about using the backlight.



- To turn on the backlight manually**  
In any mode, press **(B)** to illuminate the display for about one second.
- The above operation turns on the backlight regardless of the current auto light switch setting.

## About the Auto Light Switch

Turning on the auto light switch causes the backlight to turn on for about one second, whenever you position your wrist as described below in any mode.

Moving the watch to a position that is parallel to the ground and then tilting it towards you more than 40 degrees causes the backlight to turn on.



### Warning!

- Always make sure you are in a safe place whenever you are reading the display of the watch using the auto light switch. Be especially careful when running or engaged in any other activity that can result in accident or injury. Also take care that sudden illumination by the auto light switch does not surprise or distract others around you.
- When you are wearing the watch, make sure that its auto light switch is turned off before riding on a bicycle or operating a motorcycle or any other motor vehicle. Sudden and unintended operation of the auto light switch can create a distraction, which can result in a traffic accident and serious personal injury.


### To turn the auto light switch on and off

- In the Timekeeping Mode, hold down **(D)** for about two seconds to toggle the auto light switch on (AUTO EL displayed) and off (AUTO EL not displayed).
- The auto light switch on indicator (AUTO EL) is on the display in all modes while the auto light switch is turned on.

## Battery

This watch is equipped with a solar cell and a rechargeable battery (secondary battery) that is charged by the electrical power produced by the solar cell. The illustration shown below shows how you should position the watch for charging.

**Example:** Orient the watch so its face is pointing at a light source.



- Note that charging efficiency drops when any part of the solar cell is blocked by clothing, etc.
- The illustration shows how to position a watch with a resin band.

### Important!

- Storing the watch for long periods in an area where there is no light or wearing it in such a way that it is blocked from exposure to light can cause rechargeable battery power to run down. Be sure that the watch is normally exposed to bright light whenever possible.
- This watch employs a solar cell that converts light into electricity, which charges a built-in rechargeable battery. Normally, the rechargeable battery should not need replacement, but after very long use over a number of years, the rechargeable battery may lose its ability to achieve a full charge. Should you notice problems with getting the rechargeable battery to a full charge, contact your dealer or CASIO distributor about having the rechargeable battery replaced.
- The rechargeable battery should be replaced with a CASIO-specified CTL1616 battery only. Other rechargeable batteries can cause damage to the watch.
- All data stored in memory is deleted, and the current time and all other settings return to their initial factory defaults whenever battery power drops to Level 5 and when you have the battery replaced.
- Turn on the watch's Power Saving function and keep it in an area normally exposed to bright light when storing it for long periods. This helps to keep the rechargeable battery from going dead.

### Battery Power Indicator

The battery power indicator on the display shows you the current status of the rechargeable battery's power.



Level	Battery Power Indicator	Function Status
1		All functions enabled.
2		All functions enabled.
3		All functions enabled.
4		Beeper tone, backlight, display, and buttons are disabled. (Charge Soon Alert)
5		All functions, including timekeeping, are disabled.

- The flashing indicator at Level 4 tells you that battery power is very low, and that exposure to bright light for charging is required as soon as possible.
- At Level 5, all functions are disabled and settings return to their initial factory defaults. Functions are enabled once again after the rechargeable battery is charged, but you need to set the time, date, and all other settings after the battery is recharged to Level 3 from Level 5. Though the time appears on the display after the battery is charged to Level 4, you will not be able to change the time setting until the battery reaches Level 3.
- Leaving the watch in direct sunlight or some other very strong light source can cause the battery power indicator to temporarily show a reading that is higher than the actual battery level. The correct battery power indicator should appear after a few minutes.
- If you use the backlight or any of the alarm functions a number of times during a short period, RECOVER appears on the display and the following operations become disabled until battery power recovers.

#### Backlight

#### Beeper tone

After some time, battery power will recover and RECOVER will disappear, indicating that the above functions are enabled again.

## Charging Precautions

Certain charging conditions can cause the watch to become very hot. Avoid leaving the watch in the areas described below whenever charging its rechargeable battery.

### Warning!

Leaving the watch in bright light to charge its rechargeable battery can cause it to become quite hot. Take care when handling the watch to avoid burn injury. The watch can become particularly hot when exposed to the following conditions for long periods.

- On the dashboard of a car parked in direct sunlight
- Too close to an incandescent lamp
- Under direct sunlight

## Charging Guide

After a full charge, timekeeping remains enabled for up to about 10 months, while the watch is used under the conditions described below.

### Operating Conditions

- Watch is not exposed to light
- Display on 18 hours per day, sleep state 6 hours per day
- 1 backlight operation (1.5 seconds) per day
- 10 seconds of alarm operation per day
- 1 countdown timer operation per day

### Charge Times

Exposing the watch to light for the periods shown below each day restores the power used by the above operating conditions.

Exposure Level (Brightness)	Approximate Exposure Time
Outdoor Sunlight (50,000 lux)	5 minutes
Sunlight Through a Window (10,000 lux)	24 minutes
Daylight Through a Window on a Cloudy Day (5,000 lux)	48 minutes
Indoor Fluorescent Lighting (500 lux)	8 hours

- Stable operation is promoted by frequent charging.

### Recovery Times

The table below shows the amount exposure that is required to take the battery from one level to the next.


Exposure Level (Brightness)	Approximate Exposure Time				
	Level 5	Level 4	Level 3	Level 2	Level 1
Outdoor Sunlight (50,000 lux)	75 minutes	24 hours	5 hours		
Sunlight Through a Window (10,000 lux)	4 hours	120 hours	23 hours		
Daylight Through a Window on a Cloudy Day (5,000 lux)	8 hours	---			
Indoor Fluorescent Lighting (500 lux)	130 hours	---			

- The above exposure time values are all for reference only. Actual required exposure times depend on lighting conditions.

## Reference

This section contains more detailed and technical information about watch operation. It also contains important precautions and notes about the various features and functions of this watch.

### Power Saving Function



When turned on, the Power Saving function automatically puts the watch into a sleep state whenever it is left in an area where it is dark. The amount of time it takes before the watch enters the sleep state depends on the current battery level as shown below.

Battery Level	Approximate Time to Sleep State
1	30 hours
2 through 4	30 minutes

The sleep state is indicated by a blank screen with **SLEEP** flashing on it. In the sleep state, all functions are enabled, except for the display.

- Wearing watch inside the sleeve of clothing can cause it to enter the sleep state.

### To recover from the sleep state

Perform any one of the following operations.

- Move the watch to a well-lit area. It can take up to five seconds for the display to turn on.
- Press any button.
- Angle the watch towards your face for reading.

### To turn Power Saving on and off



1. In the Timekeeping Mode, hold down (A) until the seconds start to flash, which indicates the setting screen.
  2. Press (C) seven times until the Power Saving on/off screen appears.
  3. Press (D) to toggle Power Saving on (ON) and off (OFF).
  4. Press (A) to exit the setting screen.
- The Power Saving on indicator (SAVE) is on the display in all modes while the Power Saving is turned on.

### Auto Return Feature

If you leave a screen with flashing digits on the display for two or three minutes without performing any operation, the watch automatically saves any settings you have made up to that point and exits the setting screen.

### Initial Screens

When you enter the Alarm Mode, the data you were viewing when you last exited the mode appears first.

### Scrolling

The (B) and (D) buttons are used in various modes and setting screens to scroll through data on the display. In most cases, holding down these buttons during a scroll operation scrolls through the data at high speed.

## Timekeeping

- Resetting the seconds to 00 while the current count is in the range of 30 to 59 causes the minutes to be increased by 1. In the range of 00 to 29, the seconds are reset to 00 without changing the minutes.
- With the 12-hour format, the P (PM) indicator appears on the display for times in the range of noon to 11:59 p.m. and no indicator appears for times in the range of midnight to 11:59 a.m.
- With the 24-hour format, times are displayed in the range of 0:00 to 23:59, without any indicator.
- The year can be set in the range of 2000 to 2039.
- The watch's built-in full automatic calendar makes allowances for different month lengths and leap years. Once you set the date, there should be no reason to change it except when battery power drops to Level 5.

## Backlight Precautions

- The electro-luminescent panel that provides illumination loses power after very long use.
- The illumination provided by the backlight may be hard to see when viewed under direct sunlight.
- The watch may emit an audible sound whenever the display is illuminated. This is due to vibration of the EL panel used for illumination, and does not indicate malfunction.
- The backlight automatically turns off whenever an alarm sounds.
- Frequent use of the backlight runs down the battery.

## Auto light switch precautions

Wearing the watch on the inside of your wrist and movement or vibration of your arm can cause the auto light switch to activate and illuminate the display. To avoid running down the battery, turn off the auto light switch whenever engaging in activities that might cause frequent illumination of the display.

More than 15 degrees too high



- The backlight may not light if the face of the watch is more than 15 degrees above or below parallel. Make sure that the back of your hand is parallel to the ground.
- The backlight turns off in about one second, even if you keep the watch pointed towards your face.
- Static electricity or magnetic force can interfere with proper operation of the auto light switch. If the backlight does not light, try moving the watch back to the starting position (parallel with the ground) and then tilt it back toward you again. If this does not work, drop your arm all the way down so it hangs at your side, and then bring it back up again.
- Under certain conditions, the backlight may not light until about one second after you turn the face of the watch towards you. This does not necessarily indicate malfunction of the backlight.