

SEIKO

取扱説明書 INSTRUCTIONS

7T94

この度は弊社製品をお買い上げいただき、誠にありがとうございました。ご使用前にこの説明書をよくお読みの上、正しくご愛用くださいますよう、お願い申し上げます。なお、この説明書はお手元に保管し、必要に応じてご覧ください。


セイコーウォッチ株式会社

全国共通フリーダイヤル 0120-612-911
お客様相談室
〒100-0005東京都千代田区丸の内3-1-1 皇都ビル
〒500-0013大阪府南区新町1-4-24 大阪西橋新町ビルディング
セイコーウォッチ株式会社
本社 〒105-8467 東京都港区虎ノ門2-8-10
http://www.seiko-watch.co.jp/

FEATURES


- This is a multi-display analogue watch featuring a stopwatch function.
The current time is indicated by the hour and minute hands and a small second hand.
The stopwatch can measure up to 60 minutes in 1/5 second increments. After 12 hours, it will automatically be stopped.

DISPLAY AND CROWN/BUTTON OPERATION



CROWN


There are two types of crown, a normal crown and a screw-lock type crown. Please check the type of the crown of your watch.




※If your watch has a screw-lock type crown, the crown screws into the watch to prevent malfunction and increase water resistance. ※Be careful not to screw the crown in by force as it may damage the slots of the crown.

SETTING THE TIME AND ADJUSTING THE STOPWATCH HAND POSITION

This watch is so designed that main time setting, adjustment of the alarm hands to the current time, and stopwatch hand position adjustment are all made with the crown at the second click position. Once the crown is pulled out to the second click, be sure to make all the above adjustments at the same time.



- How to set the time
1 Pull out the crown to the second click when the small second hand is at the 12 o'clock position. The small second hand stops on the spot.




※If the stopwatch is measuring, the stopwatch hands are automatically reset to "0" position.
2 Turn the crown to set the main time hands to the desired time.




It is recommended that the hands be set to the time a few minutes ahead of the current time, taking into consideration the time required to adjust the stopwatch hand position if necessary.

- When setting the hour hand, check that AM/PM is correctly set. The watch is so designed that the date changes once in 24 hours.
When setting the minute hand, first advance it 4 to 5 minutes ahead of the desired time, and then, turn it back to the exact minute.

- 3 Press button A for 2 seconds. The stopwatch minute hand turns a full circle. Press button B repeatedly to reset the stopwatch minute hand to "0" position. It moves quickly if button B is kept pressed.



- 4 Press button A for 2 seconds. The stopwatch second hand turns a full circle. Press button B repeatedly to reset the stopwatch second hand to "0" position. It moves quickly if button B is kept pressed.



- To adjust the stopwatch minute hand again, push the crown back in to the normal position and start from procedure 1 again.
After all the adjustments are completed, push the crown back in to the normal position in accordance with a time signal.
Check that the main time hands and alarm hands indicate the identical time, and then, push the crown back in to the normal position.
The telephone time signal service (TEI 117) is helpful in setting the hands accurately.

HOW TO SET THE DATE

- Be sure to set the main time before setting the date.
It is necessary to adjust the date on the first day of March and months following 30-day months.

- 1 Pull out the crown to the first click.



- 2 Turn the crown clockwise to set the date.
Do not set the date between 9:00 p.m. and 1:00 a.m. Otherwise, the date may not change properly. If it is necessary to set the date during that time period, first change the time to any time outside it, set the date and then, reset the correct time.
After all the adjustments are completed, push the crown back in to the normal position.

HOW TO USE THE STOPWATCH

- The stopwatch can measure up to 60 minutes in 1/5 second increments. After 60 minutes, it will start counting again from "0" repeatedly up to 12 hours. After 12 hours, it will automatically stop.
Time measured is indicated by the stopwatch second hand at the center and the stopwatch minute hand at the 12 o'clock side.
Split time measurement is available.


<How to read the stopwatch hands>

Time measured is indicated by the two stopwatch hands (stopwatch second and minute hands).




<Note on adjusting the stopwatch hand position>
If the stopwatch hands do not return to "0" position when the stopwatch is reset, follow the procedure in "TIME SETTING AND ADJUSTING THE STOPWATCH HAND POSITION" to reset them.
In that case, be sure to adjust the main time hands to the current time.

- How to reset the stopwatch
When the stopwatch hands are counting:
1 Press button A to stop the stopwatch.
2 Press button B to reset the stopwatch.
When the stopwatch hands are stopped:
One of the following three stopwatch operations has been made.
Reset the stopwatch accordingly.
[The stopwatch was stopped in "Standard measurement" or "Accumulated elapsed time measurement."]
1 Press button B to reset the stopwatch.
[Split time was measured and remains displayed in "Split time measurement".]
1 Press button B. The split time is released and the stopwatch hands move quickly to indicate the measurement in progress.
2 Press button A to stop the stopwatch.
3 Press button B to reset the stopwatch.
[The time of the 2nd competitor was measured in "Measurement of two competitors".]
1 Press button B. The stopwatch hands move quickly and stop.
2 Press button B to reset the stopwatch.



HOW TO USE THE TACHYMETER (For the models with a tachymeter scale on the dial)=

- The tachymeter can be used to measure the hourly average speed of a vehicle and the hourly rate of operation.



- 1 Use the stopwatch to determine how many seconds it takes to go one kilometer.
2 Read the tachymeter scale where the second hand points. [80km/h]
1 Use the stopwatch to measure the time required to complete one product.
2 Read the tachymeter where the second hand points. [400 products/hour]

HOW TO USE THE TELEMETER (For the models with a telemeter scale on the dial)=


- The telemeter can provide a rough indication of the distance to the source of the sound.

<Telemeter>

- The telemeter shows the distance from your place to an object that emits both sound and light. For example, it can indicate the distance to the place where a lightning struck by measuring the time elapsed after you see a flash of the lightning until you hear the sound.
A flash of lightning reaches you in a moment while the sound travels to you at a speed of 0.33km/second. The distance to the source of the light and sound can be calculated on the basis of this difference.
The telemeter scale is so graduated that the sound travels at a speed of 1km in 3seconds.

CAUTION

The telemeter provides only a rough indication of the distance to the place where lightning struck, and therefore, the indication cannot be used as the guideline to avoid the danger of lightning. It should also be noted that the speed of the sound differs depending on the temperature of the atmosphere where it travels.



CAUTION

Please note that the stopwatch second hand moves in one-second increments and does not always point exactly to the graduation of the tachymeter or telemeter scale. Also note that those scale can be used only when the measured time is less than 60 seconds.

LUMIBRITE

If your watch has Lumibrite

Lumibrite is a luminous paint that absorbs the light energy of the sunlight and lighting apparatus in a short time and stores it to emit light in the dark. For example, if exposed to a light of more than 500 lux for approximately 10 minutes, Lumibrite can emit light for 3 to 5 hours.

Please note, however, that, as Lumibrite emits the light it stores, the luminance level of the light decreases gradually over time. The duration of the emitted light may also differ slightly depending on such factors as the brightness of the place where the watch is exposed to light and the distance from the light source to the watch.

In general, when coming from a place that is bright to a place that is dark, it takes human eyes some time to adapt to the darkness making it difficult to see objects initially. (Dark adaptation)

Lumibrite is luminous paint that stores and emits light, which is harmless to human beings and the environment, containing no toxic materials such as radioactive substances.

Table with 3 columns: Condition, Illumination, and values. Rows include Sunlight (Fine weather, Cloudy weather), Indoor (Window-side during daytime), and Lighting apparatus (40-watt daylight fluorescent light).

TROUBLESHOOTING

Table with 3 columns: Problem, Possible cause, and Solution. Problems include watch stops operating, date changes at 12 o'clock noon, and glass is blurred.

※For solution of troubles other than those above, contact the retailer from whom the watch was purchased.

REMARKS ON THE BATTERY

NOTES ON THE BATTERY

- Battery life: When a new normal battery is installed, this watch operates for approximately five years. However, if the stopwatch is used for more than 2 hours a day, the battery life may be less than three years.
Monitor battery: The battery in your watch may run down in less than five years after the date of purchase, as it is a monitor battery which is inserted at the factory to check the function and performance of the watch.
Battery life indicator function: When you see the small second hand moving at two-second intervals instead of the normal one-second intervals, the battery nears its end. In that case, have the battery replaced with a new one by the retailer from whom the watch was purchased.
Battery change: 1 For battery replacement, be sure to have the battery replaced with a new one at the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER, and request the genuine battery. 2 If the old battery is left in the watch for a long time, a malfunction may be caused due to battery leakage, etc. have it replaced with a new one as soon as possible. 3 Battery replacement is charged even if it runs down within the guarantee period. 4 Once the case back is opened for battery replacement or other purposes, the original water resistant quality designed for the watch may deteriorate when it is closed. When you have the battery replaced with a new one, also request the water resistance test pertaining to the water resistant quality of your watch. If your watch has 10-BAR or higher water resistant quality, be sure to have such test performed on the watch every time the battery is replaced.
Necessary procedure after battery change: After the battery is replaced with a new one, re-set the main time, adjust the stopwatch hand position. Refer to "SETTING THE TIME AND ADJUSTING THE STOPWATCH HAND POSITION".

SPECIFICATIONS

- 1. Frequency of crystal oscillator: 32,768 Hz (Hz = Hertz ... Cycles per second)
2. Loss/gain (monthly rate): Less than 15 seconds at normal temperature range (5°C~35°C)
3. Operational temperature range: -10°C~+60°C (14°F~140°F)
4. Driving system: Step motor, 3 pieces
5. Display system: Time display Hour, minute and second hands. Stopwatch display (The stopwatch can measure up to 60 minutes in 1/5 seconds.) Minute and second hands.
6. Battery: Silver oxide battery, SB-AP, 1 piece
7. Battery life: Approx. 5 years
8. IC (Integrated Circuit): C-MOS-LSI, 1 piece
※The specifications are subject to change without prior notice, for product improvement.

TO PRESERVE THE QUALITY OF YOUR WATCH

WARNING

- Immediately stop wearing the watch in the following cases.
If the watch body or band becomes edged by corrosion etc.
If the pins protrude from the band.
Immediately consult the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER.
Keep the watch and accessories out of the reach of babies and children.
Care should be taken to prevent a baby or a child accidentally swallowing the accessories. If a baby or a child swallows the battery or accessories, immediately consult a doctor, as it will be harmful to the health of the baby or child.
Do not remove the battery from the watch. Replacement of the battery requires professional knowledge and skill. Please ask a watch retailer for replacement of the battery.
Installation of an ordinary silver oxide battery can generate heat that can cause bursting and ignition.
Do not use the watch in scuba diving or saturation diving. The various tightened inspections under simulated harsh environment, which are usually required for watches designed for scuba diving or saturation diving, have not been conducted on the water-resistant watch with the BAR (barometric pressure) display. For diving, use special watches for diving.

CAUTION

- Avoid wearing or storing the watch in the following places.
Places where volatile agents (cosmetics such as polish remover, bug repellent, thinners etc.) are vaporizing.
Places where the temperature drops below 5 °C or rises above 35 °C for a long time.
Places of high humidity.
Places affected by strong magnetism or static electricity.
Dusty places.
Places affected by strong vibrations.
For watches with batteries, do not leave a dead battery compartment for a long time as it may cause battery leakage.
If you observe any allergic symptoms or skin irritation. Stop wearing the watch immediately and consult a specialist such as a dermatologist or an allergist.
Do not pour running water directly from faucet.
The water pressure of tap water from a faucet is high enough to degrade the water resistant performance of a water resistant watch for everyday life.
Do not turn or pull out the crown when the watch is wet. Water may get inside of the watch.
If the inner surface of the glass is clouded with condensation or water droplets appear inside of the watch for a long time, the water resistant performance of the watch is deteriorated. Immediately consult the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER.
Do not leave moisture, sweat and dirt on the watch for a long time.
Be aware of a risk that a water resistant watch may lessen its water resistant performance because of deterioration of the adhesive on the glass or gasket, or the development of rust on stainless steel.
Do not wear the watch while taking a bath or a sauna. Steam, soap or some components of a hot spring may accelerate the deterioration of water resistant performance of the watch.
Other cautions: Replacement of the metal band requires professional knowledge and skill. Please ask a watch retailer for replacement of the metal band, as there is a risk of hand or finger injury and fear of losing parts.
Length adjustment service for metallic bands is available at the retailer from whom the watch was purchased or SEIKO CUSTOMER SERVICE CENTER. The service may also be available on a chargeable basis at other retailers, however, some retailers may not undertake the service.
Do not disassemble or tamper with the watch.
Keep the watch out of the reach of babies and children. Extra care should be taken to avoid risks of any injury or allergic rash or itching that may be caused when they touch the watch.
When disposing of used batteries, follow the instructions of your local authorities.
If your watch is of the fob or pendant type, the strap or chain attached to the watch may damage your clothes, or injure the hand, neck, or other parts of your body.

Daily care

- The watch requires good daily care.
Wipe away moisture, sweat or dirt with a soft cloth.
After soaking the watch in seawater, be sure to wash the watch in clean pure water and wipe it dry carefully.
If your watch is rated as "non-water resistant" or "water resistant for daily use," do not wash the watch.

Water resistance

Refer the table below for the description of each degree of water resistant performance of your watch before using.

Table with 3 columns: Indication on the case back, Water resistant performance, and Condition of use. Rows include WATER RESISTANT, WATER RESISTANT 5 BAR, and WATER RESISTANT 10 (20) BAR.

Band

- The band touches the skin directly and becomes dirty with sweat or dust. Therefore, lack of care may accelerate deterioration of the band or cause skin irritation or stain on the sleeve edge. The watch requires a lot of attention for long usage.
Metallic band: Moisture, sweat or soil will cause rust even on a stainless steel band if they are left for a long time.
Lack of care may cause a yellowish or gold stain on the lower sleeve edge of shirts.
Wipe off moisture, sweat or soil with a soft cloth as soon as possible.
To clean the soil around the joint gaps of the band, wipe it out in water and then brush it off with a soft toothbrush.
(Protect the watch body from water splashes by wrapping it up in plastic wrap etc.)

- Because some titan bracelets use pins made of stainless steel, which has outstanding strength, rust may form in the stainless steel parts.
If rust advances, pins may poke out or drop out, and the watch case may fall off the bracelet, or the clasp may not open.
If a pin is poking out, personal injury may result. In such a case, refrain from using the watch and request repair.
Leather band: A leather band is susceptible to discoloration and deterioration from moisture, sweat and direct sunlight.
Wipe off moisture and sweat as soon as possible by gently blotting them up with a dry cloth.
Do not expose the watch to direct sunlight for a long time.
Please take care when wearing a watch with light-colored band, as dirt is likely to show up.
Refrain from wearing a leather band watch other than Aqua Free bands while bathing, swimming, and when working with water even if the watch itself is water-resistant enforced for daily use (10-BAR water resistant).

- Polyurethane band: A polyurethane band is susceptible to discoloration from light, and may be deteriorated by solvent or atmospheric humidity.
Especially a translucent, white, or pale colored band easily adsorbs other colors, resulting in color smears or discoloration.
Wash out dirt in water and clean it off with a dry cloth.
(Protect the watch body from water splashes by wrapping it up in plastic wrap etc.)
When the band becomes less flexible, have the band replaced with a new one. If you continue to use the band as it is, the band may develop cracks or become brittle over time.

Notes on skin irritation and allergy: Skin irritation caused by a band has various reasons such as allergy to metals or leathers, or skin reactions against friction on dust or the band itself.

Notes on the length of the band: Adjust the band to allow a little clearance with your wrist to ensure proper airflow. When wearing the watch, leave enough room to insert a finger between the band and your wrist.

- Inspection and adjustment by disassembly and cleaning (overhaul): Periodic inspection and adjustment by disassembly and cleaning (overhaul) is recommended approximately once every 3 to 4 years in order to maintain optimal performance of the watch for a long time. According to use conditions, the oil retaining condition of your watch mechanical parts may deteriorate, abrasion of the parts due to contamination of oil may advance or delay the time significantly, or the watch itself may stop. As the parts such as gasket may deteriorate, water-resistant performance may be impaired due to intrusion of perspiration and moisture. Please contact the retailer from whom the watch was purchased for inspection and adjustment by disassembly and cleaning (overhaul). For replacement of parts, please specify "SEIKO GENUINE PARTS". When asking for inspection and adjustment by disassembly and cleaning (overhaul), make sure that the gasket and push pin are also replaced with new ones.
When your watch is inspected and adjusted by disassembly and cleaning (overhauled), the movement of your watch may be replaced.

AFTER-SALE SERVICE

- Notes on guarantee and repair: Contact the retailer the watch was purchased from or SEIKO CUSTOMER SERVICE CENTER for repair or overhaul.
Within the guarantee period, present the certificate of guarantee to receive repair services.
Guarantee coverage is provided in the certificate of guarantee. Read carefully and retain it.
For repair services after the guarantee period has expired, if the functions of the watch can be restored by repair work, we will undertake repair services upon request and payment.

REPLACEMENT PARTS

- SEIKO makes it a policy to typically keep a stock of replacement parts for this watch for 7 years. Replacement parts are those which are essential to maintaining the functional integrity of the watch. Please keep in mind that if original parts are not available, they may be replaced with substitutes whose outward appearance may differ from the originals.

■特長

この時計は、基本時計とストップウォッチ機能を備えたアナログ時計です。

- 基本時計は、時・分・小秒針で表示します。
- ストップウォッチは、専用の針（分、秒）で表示する1 / 5秒単位60分計です。12時間経過で自動的にストップします。


■各部の名称とはたらき



※ねじロックリゅうず構造・ねじロックボタン構造を持っているものもあります。
 (→「■ねじロックリゅうずやねじロックボタン構造について」を参照)
 ※以降の説明では、説明に不要な部分の針を省略することがあります。

■リゅうずについて

リゅうずには、通常のものとロックできる構造のもの、2つのタイプがあります。お使いの時計のリゅうずをご確認ください。



※ねじロック式リゅうずは、ロックすることで、誤操作の防止と防水性の向上をはかることができます。
 ※ねじロック式リゅうずは、ねじを無理にしめるとねじ部をこわすおそれがありますので、ご注意ください。

■時刻合わせ・ストップウォッチ針の0位置合わせ (基本時計・ストップウォッチ針)


この時計は時刻合わせ（基本時計）とストップウォッチ針の0位置合わせは、共にリゅうず2段目で行ないます。そのため、時刻合わせ等でリゅうずを2段目に引き出した際は、下記の2つの項目を確認または合わせ直してから、リゅうずを押し込んでください。

- ・基本時計の時刻
- ・ストップウォッチ針（分針・秒針）の0位置



●時刻の合わせかた (基本時計・ストップウォッチ針の0位置合わせ)

- ①リゅうずを2段目に引き出してください。小秒針が止まります。小秒針は12時の位置に止めてください。



※ストップウォッチ計測中の場合は、ストップウォッチが強制的にリセットされます。

- ②リゅうずを回して、「基本時計」の時刻を合わせます。



この時、合わせる時刻は今から数分後の時刻に合わせることをお勧めします。その理由は、この後「ストップウォッチ針の0位置合わせ」を行うからです。すべての合わせが終わってから、リゅうずを押し込むことになるので、数分先の時刻に合わせておく必要があります。

※日付が変わるころが、午前0時です。午前午後を間違えないように合わせてください。
 ※この時、正確に合わせるために分針を正しい時刻より4〜5分進めてから針を戻して合わせてください。

- ③ボタンAを約2秒押し続けると、ストップウォッチ分針が1周回ります。ボタンBを押して、ストップウォッチ分針を「0秒位置」に合わせてください。ボタンBを押し続けると、早送りします。



- ④ボタンAを約2秒押し続けてください。ストップウォッチ秒針が1周回ります。ボタンBを押して、ストップウォッチ秒針を0秒位置に合わせて下さい。ボタンBを押し続けると、早送りします。



※ストップウォッチ分針を再度合わせたい場合は、リゅうずを押し込み、①からやり直してください。(「●時刻の合わせかた」参照)

- ⑤すべての合わせができた後、時報と同時にリゅうずを押し込みます。※時刻合わせは、電話の時報サービスTEL.117が便利です。

■日付の合わせかた

- ・時刻合わせができてから、日付を合わせてください。
- ・1ヶ月が31日でない=月の(2, 4, 6, 9, 11月)の翌月のはじめに、日付を合わせ直すときに行ないます。

- ①リゅうずを1段目まで、引き出してください。



- ②リゅうずを右に回して、日付を合わせてください。

※午後9時から午前1時までには日付を合わせないでください。この時間帯に合わせて、翌日になっても日付が変わらないことがあるので、この時間帯外で日付を合わせてください。

- ③合わせ終わったら、リゅうずを押し込んでください。

■ストップウォッチの使いかた

- ・1 / 5秒単位、60分計のストップウォッチです。12時間作動後、自動的にストップします。
- ・センターのストップウォッチ秒針と、12時位置のストップウォッチ分針で読み取ります。
- ・スプリット機能があります。(ストップウォッチの読みかた) 2本のストップウォッチ針(ストップウォッチ秒・分針)で計測時間を読み取ります。



〈ストップウォッチ針の0位置について〉
 ・ストップウォッチをリセットしても、ストップウォッチ針が0位置に戻らない場合、0位置合わせが必要です。
 ・ストップウォッチ針の0位置合わせは、基本時計の時刻合わせと同時にに行ないます。(→「■時刻合わせ・ストップウォッチ針の0位置合わせ」を参照)


(ストップウォッチのリセット方法)

- ・ストップウォッチ針が動いている場合、
 ①ボタンAでストップ
 ②ボタンBでリセット
- ・ストップウォッチ針が止まっている場合、以下の3つの場合があります。
 【ストップウォッチが止まっている】
 ①ボタンBでリセット


- 【スプリット表示でストップウォッチが計測中】
 ①ボタンBでストップウォッチ針が早送りし、その後計測状態になる。
 ②ボタンAでストップ
 ③ボタンBでリセット

- 【スプリット表示でストップ状態】
 ①ボタンBでストップウォッチ針が早送りし、その後止まる。
 ②ボタンBでリセット


●通常の使用方法




●時間計測を積算で行なう場合



●途中経過 (スプリットタイム) を計測する場合




●2人のタイムを計測する場合



=タキメーター (TACHYMETER) がついている場合=

- 単位時間あたりの時速や出来高などが簡単に測定できます。



- ①1km走するのに要した時間を計測します。
- ②秒針が指しているタキメーターの数字を読みとります。80を指しているとき **80km/時**
- ①製品1個が出来あがるのに要した時間を計測します。
- ②秒針が指しているタキメーターの数字を読みとります。400を指しているとき **400個/1時間あたり**

=テレメーター (Telemeter) がついている場合=


- 音の発生場所までの、目安の距離を算出する事が出来ます。

(テレメーターとは)

- ・「いなびかり」を見てから、その「雷鳴」が聞こえるまでの時間を測定することで、雷の発生場所からの距離を推測することができます。
- ・光 (いなびかり) は、ほぼ瞬時に届き、音 (雷鳴) は約0.33km/秒の速さで聞こえることを利用して、発生場所からの距離を算出します。
- ・1kmを3秒かかるとして、目盛りを用意してあります。

△注意

あくまでも目安の距離を算出するもので、雷からの危険を避けるための行動判断には、使用できません。また、音の速度は伝わる空間の温度によって変わります。



△注意

ストップウォッチ秒針は1 / 5秒ステップ運針するで、タキメーターやテレメーターのそれぞれの目盛と合わない部分がありますが、目安として近い数値を読みとってください。また、計測は1分以下のみで有効です。

■ルミブライトについて

お買い上げの時計がルミブライトつきの場合
 ルミブライトは、太陽光や照明のあかりを短時間 (約10分間: 500ルクス以上) で吸収して蓄え、暗い中で長時間 (約3時間〜5時間) 発光します。光が当たらなくなつてから輝度 (明るさ) は、時間の経過とともに弱まります。なお、光を蓄える際の光の強さや光の吸収度合いとルミブライトの面積によって、発光する時間や見え方に差が生じます。
 ※一般的には明るい所から暗い所へ入った場合、人の目はすぐには順応しません。初めはものが見にくいですが、時間の経過と共に見やすくなってきます。(目の暗順応)
 ※ルミブライトは、放射能などの有害物質をまったく含んでいない環境・人に安全な蓄光 (蓄えた光を放出する) 塗料です。

<照度のめやすについて>

環境	照度	明るさ (照度) のめやす
太陽光	晴れ	100,000ルクス
	くもり	10,000ルクス
	晴れ	3,000ルクス以上
屋内 (昼間窓際)	くもり	1,000〜3,000ルクス
	雨	1,000ルクス以下
	照明 (白色蛍光灯 40Wの下で)	1m 1,000ルクス 3m 500ルクス (通常室内レベル) 4m 250ルクス

■こんな時には

現象	考えられる原因	このようにしてください
時計が止まった	電池の容量がなくなった。	電池交換をお買い上げ店にご相談ください。
小秒針が2秒遅針し続ける	電池寿命切れが近づいた。	電池交換をお買い上げ店にご相談ください。
時計が一時的に進む/遅れる	寒いところ、または、寒いところへ放置した。	常温に戻れば元の精度に戻ります。時刻を合わせ直してください。この時計は気温5℃〜35℃で腕につけたときに安定した時間精度が得られるように調整されています。
	磁気を発生するもののそばに置いた。	磁気を逃がせる、元の精度に戻ります。時刻を合わせ直してください。
	落としたり強くぶつけたりまたは激しいスポーツをした。強い振動が加えられた。	元に戻らない場合には、お買い上げ店にご相談ください。時刻を合わせ直してください。
日付けが日中に変わる	時刻合わせが12時間ずれている	12時間、針を進めて時刻および日付けを合わせ直してください。
ストップウォッチをリセットしても0に戻らない	磁気や外部からの衝撃が加えられた。	ストップウォッチ針の0位置合わせをしてください。→「■時刻合わせとストップウォッチ針の0位置合わせ」を参照
ガラスのくもりが消えない	バックシートの劣化などにより時計内部に水分が入った	お買い上げ店にご相談ください。

※その他の現象は、お買い上げ店にご相談ください。

■電池についてのお問い合わせ

- (1) 電池寿命
この時計は新しい正常な電池を組み込んだ場合、その後約5年間作動します。ただし、ストップウォッチ1日2時間以内を基準としていますので、それ以上使用した場合は上記の期間に満たないうちに電池寿命が切れる場合があります。
- (2) 最初の電池
お買い上げの時計にあらかじめ組み込まれている電池は、機能・性能をみるためのモニター用です。お買い上げ後上記の期間に満たないうちに電池寿命が切れることがありますのでご了承ください。
- (3) 電池寿命切れ予告機能
小秒針が1度に2秒送るようになると、電池寿命切れが間近であることを示しています。お早めにお買い上げ店へ電池交換をご依頼ください。
- (4) 電池交換
①電池交換は、必ずお買い上げ店または、取扱店「純正電池」とご指定の上、ご用命ください。
②電池寿命切れの電池をそのまま長時間放置しますと、漏液などで故障の原因になりますので、お早めに交換してください。
③電池交換は、保証期間内でも有料となります。
④電池交換等で裏ぶたを開閉しますと当初の防水性能を維持できなくなる場合があります。電池交換の際には、お客様の時計の防水性能にあった防水検査をご依頼ください。特に10気圧以上のものは検査が必要です。
- (5) 電池交換後のお願い
電池交換後は、基本時計とストップウォッチ針の0位置合わせを行なってください。→「■時刻合わせ・ストップウォッチ針の0位置合わせ」を参照

■製品仕様

1. 水晶振動数・・・32,768Hz (Hz=1秒間の振動数)
 2. 精度・・・平均月差±15秒 (気温5℃〜35℃において腕につけた場合)
 3. 作動温度範囲・・・-10℃〜+60℃
 4. 駆動方式・・・ステッピングモーター式: 3個
 5. 表示内容・・・【時刻機能】時・分・小秒針 (1秒ステップ運針) 【ストップウォッチ機能】ストップウォッチ秒針 (1 / 5秒ステップ運針、60秒 / 1周) ストップウォッチ分針 (1分ステップ運針、60分 / 1周)
 6. 使用電池・・・小型酸化銀電池 SB-AP: 1個
 7. 電池寿命・・・約5年
ただし、1日にストップウォッチ2時間以内の使用。
 8. 電子回路・・・発振、分周、駆動回路 (C-MOS-1C)
- ※上記の製品仕様は改良のため、予告なく変更することがあります。

■使用上のご注意とお手入れについて

●製品取扱上のご注意

△警告

- ・次のような場合、ご使用を中止してください。
 ○時計本体やバンドが腐食などにより鋭利になった場合
 ○バンドのピンが飛び出してきた場合
 ※さらに、お買い上げ店・弊社お客様相談窓口にご連絡ください。
- ・乳幼児の手の届くところに、時計本体や部品を置かないでください。
 部品や電池を乳幼児が飲み込んでしまうおそれがあります。
 万が一飲み込んだ場合は、身体に害があるため、ただちに医師にご相談ください。
- ・時計から電池を取り出さないでください。
 電池の交換には、専門知識・技能が必要です。お買い上げ店にご相談ください。
 電池は充電しないでください。破裂・発熱・液漏れ・破損などのおそれがあります。
 この時計はスクーバダイビングや飽和潜水には絶対にお使いしないでください。
 スキューバダイビングや飽和潜水用の時計に必要な特殊な環境を想定した横や厳しい検査を行っていません。専用のダイブスウォッチをご使用ください。

△注意

- ・以下の場所での携帯・保管は避けてください。
 ○揮発性の薬品が散発しているところ (除光液などの化粧品、防虫剤、シンナーなど)
 ○5℃〜35℃から外れる温度に長時間なるところ
 ○高湿度なところ
 ○磁気や静電気の影響があるところ
 ○ホコリの多いところ
 ○強い振動があるところ
 ※電池式の場合は、電池が切れた状態で長時間放置しないでください。電池が漏れするおそれがあります。
- ・アレルギーやかぶれを起こした場合
 ただちに時計の使用をやめ、皮膚科など専門医にご相談ください。
- ・直接蛇口から水をつけることは避けてください。
 水道水は非常に水圧が高く、日常生活用強化防水の時計でも防水不良になるおそれがあります。
 ・水分のついたまま、リゅうずやボタンを操作しないでください。
 時計内部に水分が入ることがあります。
 ※万が一、ガラス面にくもりや水滴が発生し、長時間消えない場合は防水不良です。
 お早めに、お買い上げ店・弊社お客様相談窓口にご相談ください。
- ・水や汗、汚れが付着したままにしておくのは避けてください。
 防水時計でもガラスの接着剤やバックシートの劣化やステンレスがさびることにより、防水不良になるおそれがあります。
 ・入浴やサウナの際はご使用を避けてください。
 蒸気や石けん、温泉の成分などが防水性能の劣化を早めることがあります。
 その他ご注意
 ○金属バンドの調整は専門知識・技能が必要です。お買い上げ店にご相談ください。
 手や指などをケガする可能性があるほか、部品を紛失する可能性があります。
 ※ご鑑賞、ご転売などにより、お買い上げ店での調整が受けられない場合は、弊社お客様相談窓口へご相談ください。
 お買い上げ店以外では有料もしくはお取扱いいただけない場合があります。
 ○商品の分解・改造はしないでください。
 ○乳幼児に時計が触れないようにご注意ください。
 ケガやアレルギーをひき起こすおそれがあります。
 ○使用済み電池の処理は自治体の指示に従ってください。
 ○提げ時計やペンダント時計の場合、ひもやチェーンの取り扱いにご注意ください。
 衣服や手、首などを締めたりするおそれがあります。

●お手入れについて

- 日ごろからこまめにお手入れしてください
- ・水分や汗、汚れはこまめに柔らかい布でふき取るように心がけてください。
- ・海水につけた後は、必ず真水でよく洗ってからふき取ってください。
 その際、直接蛇口から水をつけることは避け、容器に水をためるなどしてから洗ってください。
 ※非防水・日常生活用防水の場合はおやめください。

●防水性能について

お買い上げいただいた時計の防水性能を表したご確認の上ご使用ください。

表示なし	防水性能	お取り扱い方法
	非防水	水漬がかかったり、汗を多くかく場合には、使用しないで下さい。
WATER RESISTANT	日常生活用防水	日常生活での「水がかかる」程度の環境であれば使用できます。△警告 水泳には使用しないで下さい。
WATER RESISTANT 5 BAR	日常生活用強化防水 5気圧防水	水泳などのスポーツに使用できます。
WATER RESISTANT 10 (20) BAR	日常生活用強化防水 10 (20) 気圧防水	空気ボンベを使用しないスクーバダイビングに使用できます。

- バンドについて
 バンドは直接肌に触れ、汗やほこりで汚れます。そのため、お手入れが悪いとバンドが早く傷んだり、肌のかぶれやその口の汚れなどの原因になります。
 長くお使いになるためには、こまめなお手入れが必要です。
- 金属バンド
 ・ステンレスバンドも水や汗、汚れをそのままにしておくと、さびやすくなります。
 ・手入れが悪いと、かぶれやワイシャツのそでが黄色や金色に汚れる原因になります。
 ・水や汗、汚れは、早めに柔らかい布でよくふき取ってください。
 ・バンドのすき間の汚れは、水で洗い、柔らかい歯ブラシなどで取り除いてください。
 (時計本体は水にぬれないように、台所用ラップなどで保護しておきましょう。)
 残った水分は柔らかい布でよくふき取ってください。
- ・チタンバンドでも、ピン類には強度に優れたステンレスが使用されているものがあり、ステンレスからさびが発生することがあります。
 ・さびが進行すると、ピンの飛び出しや抜けが発生し、時計を脱落させてしまうことがあります。また、逆に中留が外れなくなる場合があります。
 ・万が一、ピンが飛び出している場合は、怪我をするおそれがありますので、ただちに使用をやめて修理をご依頼ください。

- 皮革バンド
 ・水や汗、直射日光に当たると、色落ちや劣化の原因になります。
 ・水がかかったときや汗をかいた後は、すぐに乾いた布などで、吸い取るように軽くふいてください。
 ・直接日光にあたる場所には放置しないでください。
- ・色の濃いバンドは、汚れが目立ちやすいので、ご使用の際はご注意ください。
 ・時計本体が日常生活用強化防水10 (20) 気圧防水になっているものでも、アクアフリーバンド以外の皮革バンドは、水泳・水仕事などでのご使用はお控えください。

- ポリウレタンバンド
 ・光があせたり、溶剤や空気中の湿気などにより劣化する性質があります。
 ・特に半透明や白色・淡い色のバンドは、他の色を吸着しやすく、また変色をおこします。
 ・汚れたら水で洗い、乾いた布でよくふき取ってください。
 (時計本体は水にぬれないように、台所用ラップなどで保護しておきましょう。)
 ・弾力性がなくなったり取り換えてください。そのまま使い続けるとお肌割れが生じバンドが切れやすくなります。

- かぶれやアレルギーについて
 バンドによるかぶれは、金属や皮革が原因となるアレルギー反応や、汚れ、もしくはバンドとのすれなどの不快感の原因となる場合など、いろいろな発生原因があります。

- バンドサイズのためやすについて
 バンドは多少余裕をもたせ、通気性をよくしてご使用ください。
 時計をつけた状態で、指一本入る程度が適当です。
- 点検調整のための分解掃除 (オーバーホール) について
 ・長くご使用いただくために、3年〜4年に1度程度の点検調整のための分解掃除 (オーバーホール) をおすすめします。ご使用状況によっては、機械の保油状態が損なわれたり、油の汚れなどによって部品が腐蝕し、止まりにくいことがあります。
 またバックシートの劣化が進み、汗や水分の浸入などで防水性能が損なわれる場合があります。
 点検調整のための分解掃除 (オーバーホール) は、「純正部品」とご指定の上、お買い上げ店にご相談ください。その際、バックシートの交換もあわせてご依頼ください。
 ・点検調整のための分解掃除 (オーバーホール) の際には、ムーブメント交換となる場合もあります。

■アフターサービスについて

- 保証と修理について
 ・修理や点検調整のための分解掃除 (オーバーホール) の際は、お買い上げ店または弊社お客様相談窓口にご相談ください。
 ・保証期間内に不具合が生じた場合は、必ず保証書を添えてお買い上げ店へお持ちください。
 ・保証内容は保証書に記載したとおりです。
 ・保証書をよくお読みいただき、大切に保管してください。
 ・保証期間終了後については、修理によって機能が維持できる場合には、ご要望により有料修理させていただきます。

■補修用性能部品について

この時計の補修用性能部品の保有期間は通常7年を基準としています。補修用性能部品とは時計の機能を維持するために必要な修理用部品です。修理の際、外観の異なる代替部品を使用させていただくことがありますので、あらかじめご了承ください。